


Installer reference guide

R32 Split series – Domestic hot water tank



<https://daikintechicaldatahub.eu>



EKHWET90B ▲ V3 ▼
EKHWET120B ▲ V3 ▼

▲ = 1, 2, 3, ..., 9, A, B, C, ..., Z
▼ = , 1, 2, 3, ..., 9

Table of contents

1	About this document	5
1.1	Meaning of warnings and symbols	6
1.2	Installer reference guide at a glance	7
2	General safety precautions	9
2.1	For the installer	9
2.1.1	General	9
2.1.2	Installation site	10
2.1.3	Refrigerant — in case of R410A or R32	10
2.1.4	Water	12
2.1.5	Electrical	12
3	Specific installer safety instructions	15
4	About the box	20
4.1	Overview: About the box	20
4.2	Indoor unit	21
4.2.1	To unpack the indoor unit	21
4.2.2	To remove the accessories from the indoor unit	21
5	About the units and options	22
5.1	Identification	22
5.1.1	Identification label: Indoor unit	22
5.2	Possible options for the indoor unit	22
6	Application guidelines	23
6.1	Overview: Application guidelines	23
6.2	Setting up the domestic hot water tank	23
6.2.1	System layout – Standalone DHW tank	23
6.2.2	Selecting the volume and desired temperature for the DHW tank	24
6.2.3	Setup and configuration – DHW tank	25
6.3	Setting up the power consumption control	25
6.3.1	Permanent power limitation	26
6.3.2	Power limitation process	26
7	Unit installation	28
7.1	Preparing the installation site	28
7.1.1	Installation site requirements of the indoor unit	28
7.1.2	Special requirements for R32 units	29
7.1.3	Installation patterns	31
7.2	Opening and closing the units	36
7.2.1	About opening the units	36
7.2.2	To open the indoor unit	36
7.2.3	To close the indoor unit	37
7.3	Mounting the indoor unit	37
7.3.1	About mounting the indoor unit	37
7.3.2	Precautions when mounting the indoor unit	37
7.3.3	To install the indoor unit	37
8	Piping installation	39
8.1	Preparing refrigerant piping	39
8.1.1	Refrigerant piping requirements	39
8.2	Connecting refrigerant piping	39
8.2.1	To connect the refrigerant piping to the indoor unit	39
8.3	Preparing water piping	40
8.3.1	Water circuit requirements	40
8.4	Connecting water piping	42
8.4.1	About connecting the water piping	42
8.4.2	Precautions when connecting the water piping	42
8.4.3	To connect the water piping	42
8.4.4	To connect the recirculation piping	43
8.4.5	To fill the domestic hot water tank	43
9	Electrical installation	45
9.1	About connecting the electrical wiring	45
9.1.1	Precautions when connecting the electrical wiring	45
9.1.2	Guidelines when connecting the electrical wiring	46

9.1.3	About electrical compliance.....	47
9.2	Connections to the indoor unit	48
9.2.1	To connect the main power supply.....	48
9.2.2	To connect the booster heater power supply	49
9.2.3	To connect the WLAN cartridge (delivered as accessory).....	50
10	Configuration	51
10.1	Overview: Configuration	51
10.1.1	To access the most used commands	52
10.1.2	To connect the PC cable to the switch box.....	54
10.2	Configuration wizard.....	54
10.3	Possible screens	55
10.3.1	Possible screens: Overview	55
10.3.2	Home screen.....	56
10.3.3	Main menu screen.....	57
10.3.4	Menu screen.....	58
10.3.5	Setpoint screen.....	58
10.3.6	Detailed screen with values	59
10.4	Preset values and schedules.....	60
10.4.1	Using preset values.....	60
10.4.2	Using and programming schedules.....	61
10.4.3	Schedule screen: Example.....	62
10.5	Weather-dependent curve	65
10.5.1	What is a weather-dependent curve?	65
10.5.2	2-points curve	66
10.5.3	Slope-offset curve.....	67
10.5.4	Using weather-dependent curves.....	68
10.6	Settings menu	69
10.6.1	Malfunctioning	69
10.6.2	Tank.....	70
10.6.3	User settings.....	78
10.6.4	Information	81
10.6.5	Installer settings	82
10.6.6	Commissioning	87
10.6.7	User profile	88
10.6.8	Operation.....	88
10.6.9	WLAN	88
10.7	Menu structure: Overview user settings.....	91
10.8	Menu structure: Overview installer settings.....	92
11	Commissioning	93
11.1	Overview: Commissioning	93
11.2	Precautions when commissioning.....	93
11.3	Checklist before commissioning.....	94
11.4	Checklist during commissioning	94
11.4.1	Operation test run	95
11.4.2	Actuator test run	95
12	Hand-over to the user	97
13	Maintenance and service	98
13.1	Maintenance safety precautions.....	98
13.2	Yearly maintenance	98
13.2.1	Yearly maintenance indoor unit: overview	98
13.2.2	Yearly maintenance indoor unit: instructions	99
13.3	To drain the domestic hot water tank.....	100
14	Troubleshooting	101
14.1	Overview: Troubleshooting	101
14.2	Precautions when troubleshooting	101
14.3	Solving problems based on symptoms.....	102
14.3.1	Symptom: Hot water does NOT reach the desired temperature.....	102
14.3.2	Symptom: The pressure at the tapping point is temporarily unusually high.....	102
14.3.3	Symptom: Tank disinfection function is NOT completed correctly (AH-error).....	102
14.4	Solving problems based on error codes	102
14.4.1	To display the help text in case of a malfunction	103
14.4.2	Error codes: Overview	103
15	Technical data	107
15.1	Piping diagram: Indoor unit	108
15.2	Wiring diagram: Indoor unit	109

16 Glossary	112
17 Field settings table	113

1 About this document

Target audience

Authorised installers

Documentation set

This document is part of a documentation set. The complete set consists of:

- **General safety precautions:**

- Safety instructions that you must read before installing
- Format: Paper (in the box of the indoor unit)

- **Operation manual:**

- Quick guide for basic usage
- Format: Paper (in the box of the indoor unit)

- **User reference guide:**

- Detailed step-by-step instructions and background information for basic and advanced usage
- Format: Digital files on <https://www.daikin.eu>. Use the search function 🔍 to find your model.

- **Installation manual – Outdoor unit:**

- Installation instructions
- Format: Paper (in the box of the outdoor unit)

- **Installation manual – Indoor unit:**

- Installation instructions
- Format: Paper (in the box of the indoor unit)

- **Installer reference guide:**

- Preparation of the installation, good practices, reference data, ...
- Format: Digital files on <https://www.daikin.eu>. Use the search function 🔍 to find your model.

Latest revisions of the supplied documentation may be available on the regional Daikin website or via your dealer.

The original documentation is written in English. All other languages are translations.

Technical engineering data

- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of latest technical data is available on the Daikin Business Portal (authentication required).

Online tools

In addition to the documentation set, some online tools are available for installers:

▪ Heating Solutions Navigator

- Digital toolbox that offers a variety of tools to facilitate the installation and configuration of heating systems.
- To access Heating Solutions Navigator, registration to the Stand By Me platform is required. For more information, see <https://professional.standbyme.daikin.eu>.

▪ Daikin e-Care

- Mobile app for installers and service technicians that allows you to register, configure and troubleshoot heating systems.
- The mobile app can be downloaded for iOS and Android devices using the QR codes below. Registration to the Stand By Me platform is required to access the app.

App Store



Google Play



1.1 Meaning of warnings and symbols



DANGER

Indicates a situation that results in death or serious injury.



DANGER: RISK OF ELECTROCUTION

Indicates a situation that could result in electrocution.



DANGER: RISK OF BURNING/SCALDING

Indicates a situation that could result in burning/scalding because of extreme hot or cold temperatures.



DANGER: RISK OF EXPLOSION

Indicates a situation that could result in explosion.



WARNING

Indicates a situation that could result in death or serious injury.



WARNING: FLAMMABLE MATERIAL



CAUTION

Indicates a situation that could result in minor or moderate injury.



NOTICE

Indicates a situation that could result in equipment or property damage.

**INFORMATION**

Indicates useful tips or additional information.

Symbols used on the unit:

Symbol	Explanation
	Before installation, read the installation and operation manual, and the wiring instruction sheet.
	Before performing maintenance and service tasks, read the service manual.
	For more information, see the installer and user reference guide.
	The unit contains rotating parts. Be careful when servicing or inspecting the unit.

Symbols used in the documentation:

Symbol	Explanation
	Indicates a figure title or a reference to it. Example: "▲ 1–3 Figure title" means "Figure 3 in chapter 1".
	Indicates a table title or a reference to it. Example: "■ 1–3 Table title" means "Table 3 in chapter 1".

1.2 Installer reference guide at a glance

Chapter	Description
About the documentation	What documentation exists for the installer
General safety precautions	Safety instructions that you must read before installing
Specific installer safety instructions	
About the box	How to handle the box, unpack the units and remove their accessories
About the units and options	- How to identify the units - Possible combinations of units and options
Application guidelines	Various installation setups of the system
Unit installation	What to do and know to install the system, including information on how to prepare for an installation
Piping installation	What to do and know to install the piping of the system, including information on how to prepare for an installation
Electrical installation	What to do and know to install the electrical components of the system, including information on how to prepare for an installation

Chapter	Description
Finishing the outdoor unit installation	What to do after unit installation, piping installation and electrical installation
Configuration	What to do and know to configure the system after it is installed
Commissioning	What to do and know to commission the system after it is configured
Hand-over to the user	What to give and explain to the user
Maintenance and service	How to maintain and service the units
Troubleshooting	What to do in case of problems
Disposal	How to dispose of the system
Technical data	Specifications of the system
Glossary	Definition of terms
Field settings table	Table to be filled in by the installer, and kept for future reference Note: There is also an installer settings table in the user reference guide. This table has to be filled in by the installer and handed over to the user.

2 General safety precautions

In this chapter

2.1	For the installer.....	9
2.1.1	General.....	9
2.1.2	Installation site.....	10
2.1.3	Refrigerant — in case of R410A or R32.....	10
2.1.4	Water.....	12
2.1.5	Electrical.....	12

2.1 For the installer

2.1.1 General

If you are NOT sure how to install or operate the unit, contact your dealer.



DANGER: RISK OF BURNING/SCALDING

- Do NOT touch the refrigerant piping, water piping or internal parts during and immediately after operation. It could be too hot or too cold. Give it time to return to normal temperature. If you MUST touch it, wear protective gloves.
- Do NOT touch any accidental leaking refrigerant.



WARNING

Improper installation or attachment of equipment or accessories could result in electrical shock, short-circuit, leaks, fire or other damage to the equipment. ONLY use accessories, optional equipment and spare parts made or approved by Daikin.



WARNING

Make sure installation, testing and applied materials comply with applicable legislation (on top of the instructions described in the Daikin documentation).



WARNING

Tear apart and throw away plastic packaging bags so that nobody, especially NOT children, can play with them. **Possible consequence:** suffocation.



WARNING

Provide adequate measures to prevent that the unit can be used as a shelter by small animals. Small animals that make contact with electrical parts can cause malfunctions, smoke or fire.



CAUTION

Wear adequate personal protective equipment (protective gloves, safety glasses,...) when installing, maintaining or servicing the system.



CAUTION

Do NOT touch the air inlet or aluminium fins of the unit.



CAUTION

- Do NOT place any objects or equipment on top of the unit.
- Do NOT sit, climb or stand on the unit.

In accordance with the applicable legislation, it might be necessary to provide a logbook with the product containing at least: information on maintenance, repair work, results of tests, stand-by periods,...

Also, at least, following information **MUST** be provided at an accessible place at the product:

- Instructions for shutting down the system in case of an emergency
- Name and address of fire department, police and hospital
- Name, address and day and night telephone numbers for obtaining service

In Europe, EN378 provides the necessary guidance for this logbook.

2.1.2 Installation site

- Provide sufficient space around the unit for servicing and air circulation.
- Make sure the installation site withstands the weight and vibration of the unit.
- Make sure the area is well ventilated. Do NOT block any ventilation openings.
- Make sure the unit is level.

Do NOT install the unit in the following places:

- In potentially explosive atmospheres.
- In places where there is machinery that emits electromagnetic waves. Electromagnetic waves may disturb the control system, and cause malfunction of the equipment.
- In places where there is a risk of fire due to the leakage of flammable gases (example: thinner or gasoline), carbon fibre, ignitable dust.
- In places where corrosive gas (example: sulphurous acid gas) is produced. Corrosion of copper pipes or soldered parts may cause the refrigerant to leak.

2.1.3 Refrigerant — in case of R410A or R32

If applicable. See the installation manual or installer reference guide of your application for more information.



DANGER: RISK OF EXPLOSION

Pump down – Refrigerant leakage. If you want to pump down the system, and there is a leak in the refrigerant circuit:

- Do NOT use the unit's automatic pump down function, with which you can collect all refrigerant from the system into the outdoor unit. **Possible consequence:** Self-combustion and explosion of the compressor because of air going into the operating compressor.
- Use a separate recovery system so that the unit's compressor does NOT have to operate.



WARNING

During tests, **NEVER** pressurise the product with a pressure higher than the maximum allowable pressure (as indicated on the nameplate of the unit).

**WARNING**

Take sufficient precautions in case of refrigerant leakage. If refrigerant gas leaks, ventilate the area immediately. Possible risks:

- Excessive refrigerant concentrations in a closed room can lead to oxygen deficiency.
- Toxic gas might be produced if refrigerant gas comes into contact with fire.

**WARNING**

ALWAYS recover the refrigerant. Do NOT release them directly into the environment. Use a vacuum pump to evacuate the installation.

**WARNING**

Make sure there is no oxygen in the system. Refrigerant may ONLY be charged after performing the leak test and the vacuum drying.

Possible consequence: Self-combustion and explosion of the compressor because of oxygen going into the operating compressor.

**NOTICE**

- To avoid compressor breakdown, do NOT charge more than the specified amount of refrigerant.
- When the refrigerant system is to be opened, refrigerant MUST be treated according to the applicable legislation.

**NOTICE**

Make sure refrigerant piping installation complies with applicable legislation. In Europe, EN378 is the applicable standard.

**NOTICE**

Make sure the field piping and connections are NOT subjected to stress.

**NOTICE**

After all the piping has been connected, make sure there is no gas leak. Use nitrogen to perform a gas leak detection.

- In case recharge is required, see the nameplate of the unit. It states the type of refrigerant and necessary amount.
- The unit is factory charged with refrigerant and depending on pipe sizes and pipe lengths some systems require additional charging of refrigerant.
- ONLY use tools exclusively for the refrigerant type used in the system, this to ensure pressure resistance and prevent foreign materials from entering into the system.
- Charge the liquid refrigerant as follows:

If	Then
A siphon tube is present (i.e., the cylinder is marked with "Liquid filling siphon attached")	Charge with the cylinder upright. 

If	Then
A siphon tube is NOT present	Charge with the cylinder upside down. 

- Open refrigerant cylinders slowly.
- Charge the refrigerant in liquid form. Adding it in gas form may prevent normal operation.



CAUTION

When the refrigerant charging procedure is done or when pausing, close the valve of the refrigerant tank immediately. If the valve is NOT closed immediately, remaining pressure might charge additional refrigerant. **Possible consequence:** Incorrect refrigerant amount.

2.1.4 Water

If applicable. See the installation manual or installer reference guide of your application for more information.



NOTICE

Make sure water quality complies with EU directive 2020/2184.

2.1.5 Electrical



DANGER: RISK OF ELECTROCUTION

- Turn OFF all power supply before removing the switch box cover, connecting electrical wiring or touching electrical parts.
- Disconnect the power supply for more than 10 minutes, and measure the voltage at the terminals of main circuit capacitors or electrical components before servicing. The voltage MUST be less than 50 V DC before you can touch electrical components. For the location of the terminals, see the wiring diagram.
- Do NOT touch electrical components with wet hands.
- Do NOT leave the unit unattended when the service cover is removed.



WARNING

If NOT factory installed, a main switch or other means for disconnection, having a contact separation in all poles providing full disconnection under overvoltage category III condition, MUST be installed in the fixed wiring.

**WARNING**

- ONLY use copper wires.
- Make sure the field wiring complies with the applicable legislation.
- All field wiring **MUST** be performed in accordance with the wiring diagram supplied with the product.
- NEVER squeeze bundled cables and make sure they do NOT come in contact with the piping and sharp edges. Make sure no external pressure is applied to the terminal connections.
- Make sure to install earth wiring. Do NOT earth the unit to a utility pipe, surge absorber, or telephone earth. Incomplete earth may cause electrical shock.
- Make sure to use a dedicated power circuit. NEVER use a power supply shared by another appliance.
- Make sure to install the required fuses or circuit breakers.
- Make sure to install an earth leakage protector. Failure to do so may cause electrical shock or fire.
- When installing the earth leakage protector, make sure it is compatible with the inverter (resistant to high frequency electric noise) to avoid unnecessary opening of the earth leakage protector.

**WARNING**

- After finishing the electrical work, confirm that each electrical component and terminal inside the electrical components box is connected securely.
- Make sure all covers are closed before starting up the unit.

**CAUTION**

- When connecting the power supply: connect the earth cable first, before making the current-carrying connections.
- When disconnecting the power supply: disconnect the current-carrying cables first, before separating the earth connection.
- The length of the conductors between the power supply stress relief and the terminal block itself **MUST** be as such that the current-carrying wires are tightened before the earth wire is in case the power supply is pulled loose from the stress relief.

**NOTICE**

Precautions when laying power wiring:



- Do NOT connect wiring of different thicknesses to the power terminal block (slack in the power wiring may cause abnormal heat).
- When connecting wiring which is the same thickness, do as shown in the figure above.
- For wiring, use the designated power wire and connect firmly, then secure to prevent outside pressure being exerted on the terminal board.
- Use an appropriate screwdriver for tightening the terminal screws. A screwdriver with a small head will damage the head and make proper tightening impossible.
- Over-tightening the terminal screws may break them.

Install power cables at least 1 meter away from televisions or radios to prevent interference. Depending on the radio waves, a distance of 1 meter may NOT be sufficient.

**NOTICE**

ONLY applicable if the power supply is three-phase, and the compressor has an ON/OFF starting method.

If there exists the possibility of reversed phase after a momentary black out and the power goes ON and OFF while the product is operating, attach a reversed phase protection circuit locally. Running the product in reversed phase can break the compressor and other parts.

3 Specific installer safety instructions

Always observe the following safety instructions and regulations.

Application guidelines (see "6 Application guidelines" [▶ 23])



CAUTION

If there is more than one leaving water zone, ALWAYS install a mixing valve station in the main zone to decrease (in heating)/increase (in cooling) the leaving water temperature when the additional zone has demand.

Installation site (see "7.1 Preparing the installation site" [▶ 28])



WARNING

Follow the service space dimensions in this manual for correct installation of the unit. See "7.1.1 Installation site requirements of the indoor unit" [▶ 28].



WARNING

The appliance shall be stored in a room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater).



WARNING

DO NOT reuse refrigerant piping that has been used with any other refrigerant. Replace the refrigerant pipes or clean thoroughly.

Special requirements for R32 (see "7.1.2 Special requirements for R32 units" [▶ 29])



WARNING

- Do NOT pierce or burn refrigerant cycle parts.
- Do NOT use means to accelerate the defrosting process or to clean the equipment, other than those recommended by the manufacturer.
- Be aware that R32 refrigerant does NOT contain an odour.



WARNING

The appliance shall be stored so as to prevent mechanical damage and in a well-ventilated room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater).



WARNING

Make sure installation, servicing, maintenance and repair comply with instructions from Daikin and with applicable legislation and are executed ONLY by authorised persons.

Opening and closing the units (see "7.2 Opening and closing the units" [▶ 36])



DANGER: RISK OF ELECTROCUTION

Do NOT leave the unit unattended when the service cover is removed.



DANGER: RISK OF ELECTROCUTION



DANGER: RISK OF BURNING/SCALDING

Mounting the indoor unit (see "7.3 Mounting the indoor unit" [▶ 37])



WARNING

Fixing method of the indoor unit **MUST** be in accordance with the instructions from this manual. See "7.3 Mounting the indoor unit" [▶ 37].

Piping installation (see "8 Piping installation" [▶ 39])



WARNING

The field piping method **MUST** be in accordance with the instructions from this manual. See "8 Piping installation" [▶ 39].



DANGER: RISK OF BURNING/SCALDING



WARNING

Provide adequate measures to prevent that the unit can be used as a shelter by small animals. Small animals that make contact with electrical parts can cause malfunctions, smoke or fire.



WARNING

Some sections of the refrigerant circuit may be isolated from other sections caused by components with specific functions (e.g. valves). The refrigerant circuit therefore features additional service ports for vacuuming, pressure relief or pressurizing the circuit.

In case it is required to perform **brazing** on the unit, ensure that there is no pressure remaining inside the unit. Internal pressures need to be released with **ALL** the service ports indicated on the figures below opened. The location is depending on model type.



WARNING

- Only use R32 as refrigerant. Other substances may cause explosions and accidents.
- R32 contains fluorinated greenhouse gases. Its global warming potential (GWP) value is 675. Do **NOT** vent these gases into the atmosphere.
- When charging refrigerant, **ALWAYS** use protective gloves and safety glasses.

Electrical installation (see "9 Electrical installation" [▶ 45])



DANGER: RISK OF ELECTROCUTION

**WARNING**

Electrical wiring connection method **MUST** be in accordance with the instructions from:

- This manual. See "[9 Electrical installation](#)" [▶ 45].
- The wiring diagram of the indoor unit, which is delivered with the unit, located on the inside of the indoor unit switch box cover. For a translation of its legend, see "[15.2 Wiring diagram: Indoor unit](#)" [▶ 109].

**WARNING**

- All wiring **MUST** be performed by an authorised electrician and **MUST** comply with the applicable national wiring regulation.
- Make electrical connections to the fixed wiring.
- All components procured on-site and all electrical construction **MUST** comply with the applicable legislation.

**WARNING**

- If the power supply has a missing or wrong N-phase, equipment might break down.
- Establish proper earthing. Do **NOT** earth the unit to a utility pipe, surge absorber, or telephone earth. Incomplete earthing may cause electrical shock.
- Install the required fuses or circuit breakers.
- Secure the electrical wiring with cable ties so that the cables do **NOT** come in contact with sharp edges or piping, particularly on the high-pressure side.
- Do **NOT** use taped wires, extension cords, or connections from a star system. They can cause overheating, electrical shock or fire.
- Do **NOT** install a phase advancing capacitor, because this unit is equipped with an inverter. A phase advancing capacitor will reduce performance and may cause accidents.

**WARNING**

If the supply cord is damaged, it **MUST** be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

**WARNING**

ALWAYS use multicore cable for power supply cables.

**CAUTION**

Do **NOT** push or place redundant cable length into the unit.

**WARNING**

The booster heater **MUST** have a dedicated power supply and **MUST** be protected by the safety devices required by the applicable legislation.

**CAUTION**

To guarantee the unit is completely earthed, **ALWAYS** connect the booster heater power supply and the earth cable.



CAUTION

To guarantee the unit is completely earthed, ALWAYS connect the booster heater power supply and the earth cable.



INFORMATION

Details of type and rating of fuses, or rating of circuit breakers are described in "9 Electrical installation" [▶ 45].

Configuration (see "10 Configuration" [▶ 51])



CAUTION

The disinfection function settings MUST be configured by the installer according to the applicable legislation.



WARNING

Be aware that the domestic hot water temperature at the hot water tap will be equal to the value selected in field setting [2-03] after a disinfection operation.

When the high domestic hot water temperature can be a potential risk for human injuries, a mixing valve (field supply) shall be installed at the hot water outlet connection of the domestic hot water tank. This mixing valve shall secure that the hot water temperature at the hot water tap never rise above a set maximum value. This maximum allowable hot water temperature shall be selected according to the applicable legislation.



CAUTION

Make sure that the disinfection function start time [5.7.3] with defined duration [5.7.5] is NOT interrupted by possible domestic hot water demand.

Commissioning (see "11 Commissioning" [▶ 93])



WARNING

Commissioning method MUST be in accordance with the instructions from this manual. See "11 Commissioning" [▶ 93].

Maintenance and service (see "13 Maintenance and service" [▶ 98])



DANGER: RISK OF ELECTROCUTION



DANGER: RISK OF BURNING/SCALDING



CAUTION

Water coming out of the valve may be very hot.



WARNING

If the internal wiring is damaged, it has to be replaced by the manufacturer, its service agent or similarly qualified persons.

**DANGER: RISK OF BURNING/SCALDING**

The water in the tank can be very hot.

Troubleshooting (see "14 Troubleshooting" [► 101])

**DANGER: RISK OF ELECTROCUTION****DANGER: RISK OF BURNING/SCALDING****WARNING**

- When carrying out an inspection on the switch box of the unit, ALWAYS make sure that the unit is disconnected from the mains. Turn off the respective circuit breaker.
- When a safety device was activated, stop the unit and find out why the safety device was activated before resetting it. NEVER shunt safety devices or change their values to a value other than the factory default setting. If you are unable to find the cause of the problem, call your dealer.

**WARNING**

Prevent hazards due to inadvertent resetting of the thermal cut-out: power to this appliance MUST NOT be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly turned ON and OFF by the utility.

4 About the box

Keep the following in mind:

- At delivery, the unit **MUST** be checked for damage and completeness. Any damage or missing parts **MUST** be reported immediately to the claims agent of the carrier.
- Bring the packed unit as close as possible to its final installation position to prevent damage during transport.
- Prepare in advance the path along which you want to bring the unit to its final installation position.

In this chapter

4.1	Overview: About the box.....	20
4.2	Indoor unit	21
4.2.1	To unpack the indoor unit.....	21
4.2.2	To remove the accessories from the indoor unit.....	21

4.1 Overview: About the box


This chapter describes what you have to do after the box with the indoor unit is delivered on-site.

Keep the following in mind:

- At delivery, the unit **MUST** be checked for damage and completeness. Any damage or missing parts **MUST** be reported immediately to the claims agent of the carrier.
- Bring the packed unit as close as possible to its final installation position to prevent damage during transport.
- Prepare in advance the path along which you want to bring the unit to its final installation position.


4.2 Indoor unit

4.2.1 To unpack the indoor unit



4.2.2 To remove the accessories from the indoor unit

Some accessories are located inside the unit. For more information on opening the unit, see "[7.2.2 To open the indoor unit](#)" [▶ 36].



- a** WLAN cartridge
- b** General safety precautions
- c** Operation manual
- d** Indoor unit installation manual

5 About the units and options


In this chapter

5.1	Identification.....	22
5.1.1	Identification label: Indoor unit	22
5.2	Possible options for the indoor unit.....	22

5.1 Identification

5.1.1 Identification label: Indoor unit

Location



Model identification

Example: EK HW E T 120 BA V3

Code	Description
EK	European Kit – Daikin Branded
HW	Hot water for LT
E	Enamel
T	Wall mounted
120	Volume in liter
BA	Model series
V3	1~ / 230 V / 50 Hz

5.2 Possible options for the indoor unit

PC cable (EKPCAB4)

The PC cable makes a connection between the switch box of the indoor unit and a PC. It gives the possibility to update the software of the indoor unit.

For installation instructions, see:

- the installation manual of the PC cable
- "10.1.2 To connect the PC cable to the switch box" [▶ 54]

6 Application guidelines

In this chapter

6.1	Overview: Application guidelines.....	23
6.2	Setting up the domestic hot water tank	23
6.2.1	System layout – Standalone DHW tank	23
6.2.2	Selecting the volume and desired temperature for the DHW tank.....	24
6.2.3	Setup and configuration – DHW tank.....	25
6.3	Setting up the power consumption control.....	25
6.3.1	Permanent power limitation.....	26
6.3.2	Power limitation process	26

6.1 Overview: Application guidelines

The purpose of the application guidelines is to give a glance of the possibilities of the heat pump system.



NOTICE


- The illustrations in the application guidelines are meant for reference only, and are NOT to be used as detailed hydraulic diagrams. The detailed hydraulic dimensioning and balancing are NOT shown, and are the responsibility of the installer.
- For more information about the configuration settings to optimize heat pump operation, see "[10 Configuration](#)" [► 51].

This chapter contains application guidelines for:

- Setting up the domestic hot water tank
- Setting up the power consumption control

6.2 Setting up the domestic hot water tank

6.2.1 System layout – Standalone DHW tank



- A** Domestic hot water
a Cold water IN
b Hot water OUT

6.2.2 Selecting the volume and desired temperature for the DHW tank

People experience water as hot when its temperature is 40°C. Therefore, the DHW consumption is always expressed as equivalent hot water volume at 40°C. However, you can set the DHW tank temperature at a higher temperature (example: 53°C), which is then mixed with cold water (example: 15°C).

Selecting the volume and desired temperature for the DHW tank consists of:

- 1 Determining the DHW consumption (equivalent hot water volume at 40°C).
- 2 Determining the volume and desired temperature for the DHW tank.

Determining the DHW consumption

Answer the following questions and calculate the DHW consumption (equivalent hot water volume at 40°C) using typical water volumes:

Question	Typical water volume
How many showers are needed per day?	1 shower = 10 min×10 l/min = 100 l
How many baths are needed per day?	1 bath = 150 l
How much water is needed at the kitchen sink per day?	1 sink = 2 min×5 l/min = 10 l
Are there any other domestic hot water needs?	—

Example: If the DHW consumption of a family (4 persons) per day is as follows:

- 3 showers
- 1 bath
- 3 sink volumes

Then the DHW consumption = (3×100 l)+(1×150 l)+(3×10 l)=480 l

Determining the volume and desired temperature for the DHW tank

Formula	Example
$V_1 = V_2 + V_2 \times (T_2 - 40) / (40 - T_1)$	If: ▪ $V_2 = 120$ l ▪ $T_2 = 54^\circ\text{C}$ ▪ $T_1 = 15^\circ\text{C}$ Then $V_1 = 187$ l
$V_2 = V_1 \times (40 - T_1) / (T_2 - T_1)$	If: ▪ $V_1 = 480$ l ▪ $T_2 = 54^\circ\text{C}$ ▪ $T_1 = 15^\circ\text{C}$ Then $V_2 = 307$ l

- V_1 DHW consumption (equivalent hot water volume at 40°C)
 V_2 Required DHW tank volume if only heated once
 T_2 DHW tank temperature
 T_1 Cold water temperature

Possible DHW tank volumes

Type	Possible volumes
Standalone DHW tank	▪ 90 l ▪ 120 l

Energy saving tips

- If the DHW consumption differs from day to day, you can program a weekly schedule with different desired DHW tank temperatures for each day.
- The lower the desired DHW tank temperature, the more cost effective. By selecting a larger DHW tank, you can lower the desired DHW tank temperature.
- The heat pump itself can produce domestic hot water of maximum 53°C (or lower according to outdoor temperature). The electrical resistance integrated in the tank can increase this temperature. However, this consumes more energy. We recommend to set the desired DHW tank temperature below 53°C to minimize using the electrical resistance.
- In case multiple indoor units are connected to the outdoor unit: when the heat pump produces domestic hot water (DHW), depending on total demand for Air Conditioning (A/C) and the scheduled priority setting, it might not be able to do both DHW and A/C at the same time. In case you need DHW and A/C at the same, we recommend to produce the domestic hot water during the night when there is lower A/C demand or during the time when occupants are not present.

6.2.3 Setup and configuration – DHW tank

- For large DHW consumptions, you can heat up the DHW tank several times during the day.
- To heat up the DHW tank to the desired DHW tank temperature, you can use the following energy sources:
 - Thermodynamic cycle of the heat pump
 - Electrical booster heater
- For more information about:
 - Optimising the energy consumption for producing domestic hot water, see ["10 Configuration"](#) [▶ 51].
 - Connecting the water piping of the standalone DHW tank to the indoor unit, see the installation manual of the DHW tank.

6.3 Setting up the power consumption control

You can use the following power consumption controls. For more information about the corresponding settings, see ["Power consumption control"](#) [▶ 85].

#	Power consumption control
1	"6.3.1 Permanent power limitation" [▶ 26] ▪ Allows you to limit the power consumption of the entire heat pump system (sum of outdoor unit, indoor unit and booster heater) with one permanent setting. ▪ Limitation of power in kW or current in A.

**NOTICE**

Set a minimum power consumption of 3 kW to guarantee:

- Defrost operation. Otherwise, if defrosting is interrupted several times, the heat exchanger will freeze up.
- DHW production by allowing booster heater.

**NOTICE**


- In case Power Consumption Control is turned ON and activated while outdoor unit is performing Air Conditioning operation, booster heater might be prohibited. In this case, to ensure DHW production, it is recommended to set Priority Schedule to DHW (refer to "[Possible schedules](#)" [▶ 61]) and minimize Air Conditioning operation during the moments when DHW heat up is expected.

6.3.1 Permanent power limitation

Permanent power limitation is useful to assure a maximum power or current input of the system. In some countries, legislation limits the maximum power consumption for space heating and DHW production.

Setup and configuration

- No additional equipment needed.
- Set the power consumption control settings in [9.9] via the user interface (see "[Power consumption control](#)" [▶ 85]):
 - Select continuous limitation mode
 - Select the type of limitation (power in kW or current in A)
 - Set the desired power limitation level



- P_i Power input
 t Time
PLL Power Limitation Level
a Power limitation active
b Actual power input


6.3.2 Power limitation process

The outdoor unit has better efficiency than the electrical booster heaters. Therefore, the booster heater is turned OFF first. The system limits power consumption in the following order:

- 1 Turns OFF booster heater.
- 2 Limits the outdoor unit.

Example

Power consumption is limited as follows:



- P_h Produced heat
- C_e Consumed energy
- A** Outdoor unit
- B** Booster heater
- a** Limited outdoor unit operation
- b** Full outdoor unit operation
- c** Booster heater turned ON

7 Unit installation

In this chapter

7.1	Preparing the installation site	28
7.1.1	Installation site requirements of the indoor unit	28
7.1.2	Special requirements for R32 units	29
7.1.3	Installation patterns	31
7.2	Opening and closing the units	36
7.2.1	About opening the units	36
7.2.2	To open the indoor unit	36
7.2.3	To close the indoor unit	37
7.3	Mounting the indoor unit	37
7.3.1	About mounting the indoor unit	37
7.3.2	Precautions when mounting the indoor unit	37
7.3.3	To install the indoor unit	37

7.1 Preparing the installation site

Choose an installation location with sufficient space to transport the unit in and out of the site.

Do NOT install the unit in places often used as work place. In case of construction works (e.g. grinding works) where a lot of dust is created, the unit MUST be covered.



WARNING

The appliance shall be stored in a room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater).



WARNING

DO NOT reuse refrigerant piping that has been used with any other refrigerant. Replace the refrigerant pipes or clean thoroughly.



WARNING

Appliance is IPX3. When installing this product in a bathroom follow the applicable legislation for installation in such places.


7.1.1 Installation site requirements of the indoor unit



INFORMATION

Also read the precautions and requirements in the "2 General safety precautions" [▶ 9].

- The indoor unit is designed for indoor installation only and for the following ambient temperatures:
 - Domestic hot water production: 5~35°C
- Mind the following spacing installation guidelines:



Additionally to the spacing guidelines: Because the total refrigerant charge in the system is ≥ 1.84 kg, the room where you install the indoor unit must also comply with the conditions described in "[7.1.3 Installation patterns](#)" [▶ 31].

Do NOT install the unit in places such as:

- In places where a mineral oil mist, spray or vapour may be present in the atmosphere. Plastic parts may deteriorate and fall off or cause water leakage.
- Sound sensitive areas (e.g. near a bedroom), so that the operation noise will cause no trouble.
- In places where frost is possible. Ambient temperature around the indoor unit must be $>5^{\circ}\text{C}$.

7.1.2 Special requirements for R32 units

Additionally to the spacing guidelines: Because the total refrigerant charge in the system is ≥ 1.84 kg, the room where you install the indoor unit must also comply with the conditions described in "[7.1.3 Installation patterns](#)" [▶ 31].



WARNING

- Do NOT pierce or burn refrigerant cycle parts.
- Do NOT use means to accelerate the defrosting process or to clean the equipment, other than those recommended by the manufacturer.
- Be aware that R32 refrigerant does NOT contain an odour.



WARNING

The appliance shall be stored so as to prevent mechanical damage and in a well-ventilated room without continuously operating ignition sources (example: open flames, an operating gas appliance or an operating electric heater) and have a room size as specified below.



NOTICE

- Do NOT re-use joints and copper gaskets which have been used already.
- Joints made in installation between parts of refrigerant system shall be accessible for maintenance purposes.



WARNING

Make sure installation, servicing, maintenance and repair comply with instructions from Daikin and with applicable legislation and are executed ONLY by authorised persons.






NOTICE

- Protect pipework from physical damage.
- Keep the pipework installation to a minimum.

7.1.3 Installation patterns

Depending on the type of room in which you install the indoor unit, different installation patterns are allowed:


Room type	Allowed patterns
Living room, kitchen, garage, attic, basement, storage room	1, 2
Technical room (i.e. room that is NEVER occupied by persons)	1, 2, 3

	PATTERN 1	PATTERN 2	PATTERN 3
			
Ventilation openings	N/A	Between room A and B	Between room A and outside
Minimum floor area	Room A	Room A + Room B	N/A
Restrictions	See "PATTERN 1" [▶ 32], "PATTERN 2" [▶ 32], and "Tables for PATTERN 1 and 2" [▶ 33]		See "PATTERN 3" [▶ 35]

A	Room A (= room where indoor unit is installed)
B	Room B (= adjacent room)
c1	Bottom opening for natural ventilation
c2	Top opening for natural ventilation
H_{release}	Actual release height: From floor to 100 mm below top of the unit.
N/A	Not applicable


Minimum floor area / Release height:


- The minimum floor area requirements depend on the release height of the refrigerant in case of a leakage. The higher the release height, the lower the minimum floor area requirements.
- The default point of release is 100 mm below the top of the unit.
- You can also take advantage of the floor area of the adjacent room (= room B) by providing ventilation openings between the two rooms.
- For installations in technical rooms (i.e. room that is NEVER occupied by persons), additionally to patterns 1 and 2, you can also use **PATTERN 3**. For this pattern there are no requirements to the minimum floor area if you provide 2 openings (one at the bottom, one at the top) between the room and the outside to ensure natural ventilation. The room must be protected from frost.

PATTERN 1**PATTERN 2****PATTERN 2: Conditions ventilation openings**

If you want to take advantage of the floor area of the adjacent room, you must provide 2 openings (one at the bottom, one at the top) between the rooms to ensure natural ventilation. The openings must comply with the following conditions:

- **Bottom opening (A_{nv}):**
 - Must be a permanent opening that cannot be closed.
 - Must be completely located between 0 and 300 mm from the floor.
 - Must be $\geq A_{nv-min}$ (minimum bottom opening area).
 - $\geq 50\%$ of the required opening area A_{nv-min} must be ≤ 200 mm from the floor.
 - The bottom of the opening must be ≤ 100 mm from the floor.
 - If the opening starts from the floor, the height of the opening must be ≥ 20 mm.
- **Top opening:**
 - Must be a permanent opening that cannot be closed.
 - Must be $\geq 50\%$ of A_{nv-min} (minimum bottom opening area).
 - Must be ≥ 1.5 m from the floor.





Tables for PATTERN 1 and 2

Table 1: Minimum floor area

Take the following into account:

- For intermediate floor areas, use the column with the lower value. **Example:** If the floor area is 1.7 m², use the column of 1.65 m².
- For intermediate refrigerant charges, use the row with the higher value. **Example:** If the refrigerant charge is 2.35 kg, use the row of 2.4 kg.

Charge (kg)	Minimum floor area (m ²)										
	Release height (m)										
	1,23	1,35	1,50	1,65	1,80	1,95	2,10	2,25	2,40	2,55	2,70
2.2	9,81	8,14	6,60	5,80	5,31	4,90	4,55	4,25	3,99	3,75	3,54
2.3	10,72	8,90	7,21	6,06	5,55	5,13	4,76	4,44	4,17	3,92	3,70
2.4	11,67	9,69	7,85	6,49	5,80	5,35	4,97	4,64	4,35	4,09	3,87
2.5	12,66	10,51	8,52	7,04	6,04	5,57	5,18	4,83	4,53	4,26	4,03
2.6	13,70	11,37	9,21	7,61	6,40	5,80	5,38	5,02	4,71	4,43	4,19

Table 2: Minimum release height

Take the following into account:

- For intermediate floor areas, use the column with the lower value. **Example:** If the floor area is 5 m², use the column of 4.00 m².
- For intermediate refrigerant charges, use the row with the higher value. **Example:** If the refrigerant charge is 2.35 kg, use the row of 2.4 kg.

Charge (kg)	Minimum release height (m)						
	Floor area (m ²)						
	2,00	4,00	6,00	8,00	10,00	12,00	14,00
2.2	4,88	2,49	1,70	1,47	(*)	(*)	(*)
2.3	5,10	2,60	1,77	1,53	1,38	(*)	(*)
2.4	5,32	2,71	1,84	1,59	1,43	(*)	(*)
2.5	5,53	2,82	1,91	1,65	1,49	1,37	(*)
2.6	5,75	2,93	1,99	1,71	1,54	1,42	(*)

Table 3: Minimum bottom opening area for natural ventilation

Take the following into account:

- Use the correct table. For intermediate refrigerant charges, use the table with the higher value. **Example:** If the refrigerant charge is 2.34 kg, use the table of 2.4 kg.
- For intermediate floor areas, use the column with the lower value. **Example:** If the floor area is 5 m², use the column of 4.00 m².
- For intermediate release height values, use the row with the lower value. **Example:** If the release height is 2.20 m, use the row of 2.05 m.
- A_{nv}: Bottom opening area for natural ventilation.
- A_{nv-min}: Minimum bottom opening area for natural ventilation.
- (*) : Already OK (no ventilation openings needed).

Release height (m)	A _{nv-min} (dm ²) – In case of Refrigerant charge=2.2 kg						
	Floor area of room A (m ²) [! NOT room A + room B !]						
	2,00	4,00	6,00	8,00	10,00	12,00	14,00
1.23	4,7	3,1	1,5	0,7	(*)	(*)	(*)
1.45	4,0	2,3	0,6	(*)	(*)	(*)	(*)
1.65	3,6	1,7	(*)	(*)	(*)	(*)	(*)
1.85	3,2	1,2	(*)	(*)	(*)	(*)	(*)
2.05	2,8	0,7	(*)	(*)	(*)	(*)	(*)
2.25	2,5	0,3	(*)	(*)	(*)	(*)	(*)
2.45	2,2	(*)	(*)	(*)	(*)	(*)	(*)
2.65	1,9	(*)	(*)	(*)	(*)	(*)	(*)


Release height (m)	A _{nv-min} (dm ²) – In case of Refrigerant charge=2.4 kg						
	Floor area of room A (m ²) [! NOT room A + room B !]						
	2,00	4,00	6,00	8,00	10,00	12,00	14,00
1.23	5,2	3,6	2,0	1,3	0,6	(*)	(*)
1.45	4,6	2,8	1,1	0,2	(*)	(*)	(*)
1.65	4,1	2,2	0,3	(*)	(*)	(*)	(*)
1.85	3,6	1,7	(*)	(*)	(*)	(*)	(*)
2.05	3,2	1,2	(*)	(*)	(*)	(*)	(*)
2.25	2,9	0,7	(*)	(*)	(*)	(*)	(*)
2.45	2,6	0,3	(*)	(*)	(*)	(*)	(*)
2.65	2,3	(*)	(*)	(*)	(*)	(*)	(*)

Release height (m)	A _{nv-min} (dm ²) – In case of Refrigerant charge=2.6 kg						
	Floor area of room A (m ²) [! NOT room A + room B !]						
	2,00	4,00	6,00	8,00	10,00	12,00	14,00
1.23	5,8	4,2	2,6	1,9	1,3	0,6	(*)
1.45	5,1	3,3	1,6	0,8	(*)	(*)	(*)
1.65	4,5	2,7	0,8	(*)	(*)	(*)	(*)
1.85	4,1	2,1	0,2	(*)	(*)	(*)	(*)
2.05	3,7	1,6	(*)	(*)	(*)	(*)	(*)
2.25	3,3	1,2	(*)	(*)	(*)	(*)	(*)

A_{nv-min} (dm ²) – In case of Refrigerant charge=2.6 kg							
Release height (m)	Floor area of room A (m ²) [! NOT room A + room B !]						
	2,00	4,00	6,00	8,00	10,00	12,00	14,00
2.45	3,0	0,7	(*)	(*)	(*)	(*)	(*)
2.65	2,7	0,4	(*)	(*)	(*)	(*)	(*)

PATTERN 3

PATTERN 3 is only allowed for installations in technical rooms (i.e. room that is NEVER occupied by persons). For this pattern there are no requirements to the minimum floor area if you provide 2 openings (one at the bottom, one at the top) between the room and the outside to ensure natural ventilation. The room must be protected from frost.



A	Unoccupied room where the indoor unit is installed. Must be protected from frost.
a1	A_{nv}: Bottom opening for natural ventilation between the unoccupied room and the outside. - Must be a permanent opening that cannot be closed. - Must be above ground level. - Must be completely located between 0 and 300 mm from the floor of the unoccupied room. - Must be $\geq A_{nv-min}$ (minimum bottom opening area as specified in the table below). $\geq 50\%$ of the required opening area A_{nv-min} must be ≤ 200 mm from the floor of the unoccupied room. - The bottom of the opening must be ≤ 100 mm from the floor of the unoccupied room. - If the opening starts from the floor, the height of the opening must be ≥ 20 mm.
a2	Top opening for natural ventilation between room A and the outside. - Must be a permanent opening that cannot be closed. - Must be $\geq 50\%$ of A_{nv-min} (minimum bottom opening area as specified in the table below). - Must be ≥ 1.5 m from the floor of the unoccupied room.

A_{nv-min} (minimum bottom opening area for natural ventilation)

The minimum bottom opening area for natural ventilation between the unoccupied room and the outside depends on the total refrigerant in the system. For intermediate refrigerant charges, use the row with the higher value. **Example:** If the refrigerant charge is 2.55 kg, use the row of 2.6 kg.

Total refrigerant charge (kg)	A_{nv-min} (dm ²)
2.20	7.5
2.30	7.7
2.40	7.9
2.50	8.0
2.60	8.2

7.2 Opening and closing the units

7.2.1 About opening the units

At certain times, you have to open the unit. **Example:**


- When connecting the electrical wiring
- When maintaining or servicing the unit


DANGER: RISK OF ELECTROCUTION


Do NOT leave the unit unattended when the service cover is removed.

7.2.2 To open the indoor unit


- 1 Remove the bottom cover to be able to guide the cables to the switch box.



- 2 Remove the top cover.



- 3 Remove the switch box cover.



7.2.3 To close the indoor unit

- 1 Reinstall the switch box cover.
- 2 Reinstall the top cover.
- 3 Reinstall the bottom cover.



NOTICE

When closing the indoor unit cover, make sure that the tightening torque does NOT exceed 2.94 N•m.

7.3 Mounting the indoor unit

7.3.1 About mounting the indoor unit

When

You have to mount the outdoor and indoor unit before you can connect the refrigerant and water piping.

7.3.2 Precautions when mounting the indoor unit




INFORMATION

Also read the precautions and requirements in the following chapters:


- "2 General safety precautions" [▶ 9]
- "7.1 Preparing the installation site" [▶ 28]

7.3.3 To install the indoor unit

- 1 Install 2 plugs into the wall and insert (but not completely) 2 bolts with washers into the plugs.




2 Lift the unit.



3 Attach the unit to the wall:

- Locate the bracket on the back of the unit above the 2 bolts.
- Lower the bracket on the back of the unit over the 2 bolts.
- Tighten the 2 bolts.
- Make sure the unit is fixed properly.



8 Piping installation

In this chapter

8.1	Preparing refrigerant piping	39
8.1.1	Refrigerant piping requirements	39
8.2	Connecting refrigerant piping	39
8.2.1	To connect the refrigerant piping to the indoor unit	39
8.3	Preparing water piping	40
8.3.1	Water circuit requirements	40
8.4	Connecting water piping	42
8.4.1	About connecting the water piping	42
8.4.2	Precautions when connecting the water piping	42
8.4.3	To connect the water piping	42
8.4.4	To connect the recirculation piping	43
8.4.5	To fill the domestic hot water tank	43

8.1 Preparing refrigerant piping

8.1.1 Refrigerant piping requirements



INFORMATION

Also read the precautions and requirements in the "[2 General safety precautions](#)" [▶ 9].

- **Piping connections:** Only flare and brazed connections are allowed. The indoor and outdoor units have flare connections. Connect both ends without brazing. If brazing should be needed, take the guidelines in the outdoor unit installer reference guide into account.

Also see "[7.1.2 Special requirements for R32 units](#)" [▶ 29] for additional requirements.

For information related with piping length, diameter, connections and insulation see the Installation manual – Outdoor unit.

8.2 Connecting refrigerant piping

See the installation manual of the outdoor unit for all guidelines, specifications and installation instructions.

8.2.1 To connect the refrigerant piping to the indoor unit



NOTICE


Make sure the tank stop valves are completely open.



INFORMATION

The stop valves are factory open and the refrigerant circuit of the tank is NOT charged.

- 1 Connect the liquid stop valve from the outdoor unit to the refrigerant liquid stop valve of the indoor unit.



- a Refrigerant liquid stop valve
b Refrigerant gas stop valve

- 2 Connect the gas stop valve from the outdoor unit to the refrigerant gas stop valve of the indoor unit.

8.3 Preparing water piping

8.3.1 Water circuit requirements



INFORMATION

Also read the precautions and requirements in the "2 General safety precautions" [▶ 9].



NOTICE


In case of plastic pipes, make sure they are fully oxygen diffusion tight according to DIN 4726. The diffusion of oxygen into the piping can lead to excessive corrosion.

- **Connecting piping – Legislation.** Make all piping connections in accordance with the applicable legislation and the instructions in the "Installation" chapter, respecting the water inlet and outlet.
- **Connecting piping – Force.** Do NOT use excessive force when connecting the piping. Deformation of the piping can cause malfunctioning of the unit.
- **Connecting piping – Tools.** Only use appropriate tooling to handle brass, which is a soft material. If NOT, pipes will get damaged.
- **Connecting piping – Air, moisture, dust.** If air, moisture or dust gets into the circuit, problems may occur. To prevent this:
 - ONLY use clean pipes.
 - Hold the pipe end downwards when removing burrs.
 - Cover the pipe end when inserting it through a wall, to prevent dust and/or particles from entering the pipe.
 - Use a decent thread sealant to seal connections.
 - When using non-brass metallic piping, make sure to insulate both materials from each other to prevent galvanic corrosion.
 - Because brass is a soft material, use appropriate tooling for connecting the water circuit. Inappropriate tooling will cause damage to the pipes.
- **Glycol.** For safety reasons, it is NOT allowed to add any kind of glycol to the water circuit.
- **Piping length.** It is recommended to avoid long runs of piping between the domestic hot water tank and the hot water end point (shower, bath,...) and to avoid dead ends.

- **Field supply components – Water.** Only use materials that are compatible with water used in the system and with the materials used in the indoor unit.
- **Field supply components – Water pressure and temperature.** Check that all components in the field piping can withstand the water pressure and water temperature.
- **Water pressure – Domestic hot water.** The maximum water pressure is 7 bar (=0.7 MPa), and must be in accordance with the applicable legislation. Provide adequate safeguards in the water circuit to ensure that the maximum pressure is NOT exceeded (see "8.4.3 To connect the water piping" [▶ 42]). The minimum water pressure to operate is 1 bar (=0.1 MPa).
- **Water temperature.** All installed piping and piping accessories (valve, connections,...) MUST withstand the following temperatures:


**INFORMATION**

The following figure is an example and may NOT completely match your system layout



- **Air vents.** Provide air vents at all high points of the system, which must also be easily accessible for servicing.
- **Non-brass metallic piping.** When using non-brass metallic piping, insulate the brass and non-brass properly so that they do NOT make contact with each other. This to prevent galvanic corrosion.
- **Valve – Change-over time.** When using a 2-way valve or a 3-way valve in the water circuit, the maximum change-over time of the valve must be 60 seconds.
- **Domestic hot water tank – Capacity.** To avoid stagnation of water, it is important that the storage capacity of the domestic hot water tank meets the daily consumption of domestic hot water.
- **Domestic hot water tank – After installation.** Immediately after installation, the domestic hot water tank must be flushed with fresh water. This procedure must be repeated at least once a day the first 5 consecutive days after installation.
- **Domestic hot water tank – Standstills.** In cases where during longer periods of time there is no consumption of hot water, the equipment MUST be flushed with fresh water before usage.
- **Thermostatic mixing valves.** In accordance with the applicable legislation, it may be necessary to install thermostatic mixing valves.
- **Hygienic measures.** The installation must be in compliance with the applicable legislation and may require additional hygienic installation measures.
- **Domestic hot water tank – Disinfection.** For the disinfection function of the domestic hot water tank, see "10.6.2 Tank" [▶ 70].

- **Recirculation pump.** In accordance with the applicable legislation, it may be required to connect a recirculation pump in between the hot water end point and the cold water connection of the domestic hot water tank.



- a Cold water connection
- b Hot water connection
- c Shower
- d Recirculation pump
- e Non-return valve

8.4 Connecting water piping

8.4.1 About connecting the water piping

Before connecting the water piping

Make sure the outdoor and indoor unit are mounted.

Typical workflow

Connecting the water piping typically consists of the following stages:

- 1 Connecting the water piping to the indoor unit.
- 2 Filling the domestic hot water tank.
- 3 Insulating the water piping.

8.4.2 Precautions when connecting the water piping



INFORMATION

Also read the precautions and requirements in the following chapters:

- "2 General safety precautions" [▶ 9]
- "8.3 Preparing water piping" [▶ 40]


8.4.3 To connect the water piping



NOTICE


Do NOT use excessive force when connecting the field piping and make sure the piping is aligned properly. Deformation of the piping can cause malfunctioning of the unit.

- 1 Connect the domestic hot water in and out pipes to the indoor unit.



- a** DHW – hot water OUT (screw connection, ½")
b DHW – cold water IN (screw connection, ½")

- 2** Install the following components (field supply) on the cold water inlet of the DHW tank:



- a** DHW – hot water OUT (screw connection, ½")
b DHW – cold water IN (screw connection, ½")
c Shut-off valve (recommended)
d Non-return valve (recommended)
e Pressure reducing valve (recommended)
***f** Pressure relief valve (max. 7 bar (=0.7 MPa))(mandatory)
***g** Tundish (mandatory)
h Expansion vessel (recommended)



WARNING

Do NOT install any valves between the domestic hot water tank and the pressure relief valve.



NOTICE

A pressure relief valve (field supply) with an opening pressure of maximum 7 bar (=0.7 MPa) must be installed on the domestic cold water inlet connection in accordance with the applicable legislation.



NOTICE

To avoid damage to the surroundings in case of water leakage, it is recommended to close the domestic cold water inlet shut-off valves during periods of absence.

8.4.4 To connect the recirculation piping

If recirculation is required in your system, the water return to the tank must be from the cold water inlet.

A check valve must be installed to prevent water return to the supply system

8.4.5 To fill the domestic hot water tank

- 1** Open every hot water tap in turn to purge air from the system pipe work.
- 2** Open the cold water supply valve.

- 3** Close all water taps after all air is purged.
- 4** Check for water leaks.
- 5** Manually operate the field-installed pressure relief valve to ensure a free water flow through the discharge pipe.

9 Electrical installation

In this chapter

9.1	About connecting the electrical wiring	45
9.1.1	Precautions when connecting the electrical wiring	45
9.1.2	Guidelines when connecting the electrical wiring	46
9.1.3	About electrical compliance	47
9.2	Connections to the indoor unit	48
9.2.1	To connect the main power supply	48
9.2.2	To connect the booster heater power supply	49
9.2.3	To connect the WLAN cartridge (delivered as accessory).....	50

9.1 About connecting the electrical wiring

Typical workflow

Connecting the electrical wiring typically consists of the following stages:

- "9.2 Connections to the indoor unit" [▶ 48]

9.1.1 Precautions when connecting the electrical wiring



DANGER: RISK OF ELECTROCUTION



WARNING

- All wiring MUST be performed by an authorised electrician and MUST comply with the applicable national wiring regulation.
- Make electrical connections to the fixed wiring.
- All components procured on-site and all electrical construction MUST comply with the applicable legislation.



WARNING

ALWAYS use multicore cable for power supply cables.



INFORMATION

Also read the precautions and requirements in the "2 General safety precautions" [▶ 9].



WARNING

- If the power supply has a missing or wrong N-phase, equipment might break down.
- Establish proper earthing. Do NOT earth the unit to a utility pipe, surge absorber, or telephone earth. Incomplete earthing may cause electrical shock.
- Install the required fuses or circuit breakers.
- Secure the electrical wiring with cable ties so that the cables do NOT come in contact with sharp edges or piping, particularly on the high-pressure side.
- Do NOT use taped wires, extension cords, or connections from a star system. They can cause overheating, electrical shock or fire.
- Do NOT install a phase advancing capacitor, because this unit is equipped with an inverter. A phase advancing capacitor will reduce performance and may cause accidents.



CAUTION

Do NOT push or place redundant cable length into the unit.



NOTICE

The distance between the high voltage and low voltage cables should be at least 50 mm.

9.1.2 Guidelines when connecting the electrical wiring

Keep the following in mind:




NOTICE

We recommend using solid (single-core) wires. If stranded wires are used, slightly twist the strands to consolidate the end of the conductor for either direct use in the terminal clamp or insertion in a round crimp-style terminal.

To prepare stranded conductor wire for installation


Method 1: Twisting conductor

- 1 Strip insulation (20 mm) from the wires.
- 2 Slightly twist the end of the conductor to create a "solid-like" connection.



Method 2: Using round crimp-style terminal

- 1 Strip insulation from wires and slightly twist the end of each wire.
- 2 Install a round crimp-style terminal on the end of the wire. Place the round crimp-style terminal on the wire up to the covered part and fasten the terminal with the appropriate tool.



Use the following methods for installing wires:

Wire type	Installation method
Single-core wire Or Stranded conductor wire twisted to "solid-like" connection	a Curled wire (single-core or twisted stranded conductor wire) b Screw c Flat washer
Stranded conductor wire with round crimp-style terminal	a Terminal b Screw c Flat washer ✓ Allowed ✗ NOT allowed

Tightening torques

Indoor unit:

Item	Tightening torque (N•m)
X2M	2.45 ±10%
X5M	0.88 ±10%
X8M	2.45 ±10%
M4 (earth)	1.47 ±10%

9.1.3 About electrical compliance

Only for the booster heater of the indoor unit

See "9.2.2 To connect the booster heater power supply" [▶ 49].


9.2 Connections to the indoor unit


Item	Description
Power supply (main)	See "9.2.1 To connect the main power supply" [▶ 48].
Power supply (booster heater)	See "9.2.2 To connect the booster heater power supply" [▶ 49].
WLAN cartridge	See "9.2.3 To connect the WLAN cartridge (delivered as accessory)" [▶ 50]

9.2.1 To connect the main power supply

- 1 Open the following (see "7.2.2 To open the indoor unit" [▶ 36]):
- 2 Connect the main power supply.

	Interconnection cable (= main power supply)	Wires: (3+GND)×1.5 mm ²
	—	





9.2.2 To connect the booster heater power supply

	Booster heater cable	Wires: (2+GND)×1.5 mm ²
	[9.4]Booster heater	



WARNING


The booster heater **MUST** have a dedicated power supply and **MUST** be protected by the safety devices required by the applicable legislation.




CAUTION

To guarantee the unit is completely earthed, **ALWAYS** connect the booster heater power supply and the earth cable.

Connect the booster heater power supply as follows:






a	Booster heater power supply cable
b	Field wiring

9.2.3 To connect the WLAN cartridge (delivered as accessory)

	[D] Wireless gateway
--	----------------------

- 1 Insert the WLAN cartridge into the cartridge slot on the user interface of the indoor unit.



WARNING

In order to keep IPX3, the rubber part must be correctly fixed after WLAN installation.

See the installer reference guide for more information.

10 Configuration

In this chapter

10.1	Overview: Configuration.....	51
10.1.1	To access the most used commands	52
10.1.2	To connect the PC cable to the switch box	54
10.2	Configuration wizard	54
10.3	Possible screens.....	55
10.3.1	Possible screens: Overview.....	55
10.3.2	Home screen	56
10.3.3	Main menu screen	57
10.3.4	Menu screen.....	58
10.3.5	Setpoint screen	58
10.3.6	Detailed screen with values	59
10.4	Preset values and schedules.....	60
10.4.1	Using preset values	60
10.4.2	Using and programming schedules	61
10.4.3	Schedule screen: Example	62
10.5	Weather-dependent curve.....	65
10.5.1	What is a weather-dependent curve?.....	65
10.5.2	2-points curve.....	66
10.5.3	Slope-offset curve	67
10.5.4	Using weather-dependent curves	68
10.6	Settings menu	69
10.6.1	Malfunctioning	69
10.6.2	Tank	70
10.6.3	User settings.....	78
10.6.4	Information.....	81
10.6.5	Installer settings	82
10.6.6	Commissioning	87
10.6.7	User profile.....	88
10.6.8	Operation	88
10.6.9	WLAN.....	88
10.7	Menu structure: Overview user settings.....	91
10.8	Menu structure: Overview installer settings.....	92

10.1 Overview: Configuration

This chapter describes what you have to do and know to configure the system after it is installed.

Why

If you do NOT configure the system correctly, it might NOT work as expected. The configuration influences the following:

- The calculations of the software
- What you can see on and do with the user interface

How

You can configure the system via the user interface.

- **First time – Configuration wizard.** When you turn ON the user interface for the first time (via the unit), the configuration wizard starts to help you configure the system.
- **Restart the configuration wizard.** If the system is already configured, you can restart the configuration wizard. To restart the configuration wizard, go to **Installer settings > Configuration wizard**. To access **Installer settings**, see "[10.1.1 To access the most used commands](#)" [► 52].

- **Afterwards.** If necessary, you can make changes to the configuration in the menu structure or the overview settings.



INFORMATION

When the configuration wizard is finished, the user interface will show an overview screen and request to confirm. When confirmed, the system will restart and the home screen will be displayed.

Accessing settings – Legend for tables

You can access the installer settings using two different methods. However, NOT all settings are accessible via both methods. If so, the corresponding table columns in this chapter are set to N/A (not applicable).

Method	Column in tables
Accessing settings via the breadcrumb in the home menu screen or the menu structure . To enable breadcrumbs, press the ? button in the home screen.	# For example: [5.5]
Accessing settings via the code in the overview field settings .	Code For example: [6-0D]


See also:

- "To access the installer settings" [▶ 53]
- "10.8 Menu structure: Overview installer settings" [▶ 92]

10.1.1 To access the most used commands


To change the user permission level

You can change the user permission level as follows:

1	Go to [B]: User profile. 	
2	Enter the applicable pin code for the user permission level. ▪ Browse through the list of digits and change the selected digit. ▪ Move the cursor from left to right. ▪ Confirm the pin code and proceed.	—   


Installer pin code

The **Installer** pin code is **5678**. Additional menu items and installer settings are now available.




Advanced user pin code

The **Advanced user** pin code is **1234**. Additional menu items for the user are now visible.



User pin code

The **User** pin code is **0000**.






To access the installer settings

- 1 Set the user permission level to **Installer**.
- 2 Go to [9]: **Installer settings**.

To modify an overview setting

Example: Modify [2-02] from 23 to 3.

Most settings can be configured via the menu structure. If for any reason it is required to change a setting using the overview settings, then the overview settings can be accessed as follows:

1	Set the user permission level to Installer . See "To change the user permission level" [► 52].	—
2	Go to [9.1]: Installer settings > Overview field settings .	
3	Turn the left dial to select the first part of the setting and confirm by pressing the dial. 	
4	Turn the left dial to select the second part of the setting 	
5	Turn the right dial to modify the value from 23 to 3. 	
6	Press the left dial to confirm the new setting.	
7	Press the center button to go back to the home screen.	



INFORMATION


When you change the overview settings and you go back to the home screen, the user interface will show a popup screen and request to restart the system.
When confirmed, the system will restart and recent changes will be applied.

10.1.2 To connect the PC cable to the switch box


This connection between PC and hydro PCB is needed when updating the hydro software and EEPROM.

Prerequisite: The EKPCCAB4 kit is required.

- 1 Connect the USB connector of the cable to your PC.
- 2 Connect the plug of the cable to X10A on A1P of the switch box of the indoor unit.



- 3 Pay special attention to the position of the plug!



10.2 Configuration wizard

After first power ON of the system, the user interface starts a configuration wizard. Use this wizard to set the most important initial settings for the unit to run properly. If required, you can afterwards configure more settings. You can change all these settings via the menu structure.

You can find a short overview of the settings in the configuration here. All the settings can also be adjusted in the settings menu (use the breadcrumbs).


For the setting...	Refer to...
Language [7.1]	
Time/date [7.2]	

For the setting...		Refer to...
	Hours	—
	Minutes	
	Year	
	Month	
	Day	
System		
	Indoor unit type (read only)	"10.6.5 Installer settings" [▶ 82]
	Domestic hot water (not adjustable)	
	Emergency [9.5.1]	
	Booster heater capacity [9.4.1]	"10.6.5 Installer settings" [▶ 82]
Tank		
	Heat up mode [5.6]	"10.6.2 Tank" [▶ 70]
	Comfort setpoint [5.2]	
	Eco setpoint [5.3]	
	Reheat setpoint [5.4]	
	Hysteresis [5.9] and [5.A]	
	Operation mode [5.G]	

10.3 Possible screens


10.3.1 Possible screens: Overview

The most common screens are as follows:



10.3.2 Home screen

Press the  button to go back to the home screen. You see an overview of the unit configuration and the room and setpoint temperatures. Only symbols applicable for your configuration are visible on the home screen.




Possible actions on this screen	
	Go through the list of the main menu.
	Go to the main menu screen.
	Enable/disable breadcrumbs.

Item		Description
a	Domestic hot water	
	a1	 Domestic hot water
	a2	 Measured tank temperature ^(a)
b	Disinfection / Powerful	
		Disinfection mode active
		Powerful operation mode active
c	Emergency	
		Heat pump failure and system operates in Emergency mode.
d	Current date and time	
e	Outdoor / quiet mode	
	e1	 Measured outdoor temperature ^(a)
	e2	 Quiet mode active
	e3	 Outdoor unit
f	Indoor unit / domestic hot water tank	
	f	 Domestic hot water tank
g	Holiday mode	
		Holiday mode active
h	Malfunction	
		A malfunction occurred.
		See "14.4.1 To display the help text in case of a malfunction" [▶ 103] for more information.

^(a) If the corresponding operation is not active, the circle is greyed out.

10.3.3 Main menu screen

Starting from the home screen, press () or turn () the left dial to open the main menu screen. From the main menu, you can access the different setpoint screens and submenus.



a Selected submenu


Possible actions on this screen	
	Go through the list.
	Enter the submenu.
?	Enable/disable breadcrumbs.

Submenu		Description
[0]	 or  Malfunctioning	Restriction: Only displayed if a malfunction occurs. See "14.4.1 To display the help text in case of a malfunction" [▶ 103] for more information.
[5]	 Tank	Set the domestic hot water tank temperature.
[7]	 User settings	Gives access to user settings such as holiday mode and quiet mode.
[8]	 Information	Displays data and information about the indoor unit.
[9]	 Installer settings	Restriction: Only for the installer. Gives access to advanced settings.
[A]	 Commissioning	Restriction: Only for the installer. Perform tests and maintenance.
[B]	 User profile	Change the active user profile.
[C]	 Operation	Turn heating/cooling functionality and domestic hot water preparation on or off.
[D]	 Wireless gateway	Restriction: Only displayed if a wireless LAN (WLAN) is installed. Contains settings needed when configuring the ONECTA app. See the user reference guide for more information.

10.3.4 Menu screen



Example:





Possible actions on this screen	
	Go through the list.
	Enter the submenu/setting.

10.3.5 Setpoint screen

The setpoint screen is displayed for screens describing system components that need a setpoint value.

Example


[5] Tank temperature screen

**Explanation****Possible actions on this screen**


	Go through the list of the submenu.
	Go to the submenu.
	Adjust and automatically apply the desired temperature.

Item	Description	
Minimum temperature limit	a1	Fixed by the unit
	a2	Restricted by the installer
Maximum temperature limit	b1	Fixed by the unit
	b2	Restricted by the installer
Current temperature	c	Measured by the unit
Desired temperature	d	Turn the right dial to increase/decrease (for Reheat only mode).
Submenu	e	Turn or press the left dial to go to the submenu.

10.3.6 Detailed screen with values



- a** Settings
- b** Values
- c** Selected setting and value

Example:**Possible actions on this screen**

	Go through the list of settings.
	Change the value.
	Go to the next setting.

Possible actions on this screen	
	Confirm changes and proceed.

10.4 Preset values and schedules

10.4.1 Using preset values

About preset values

For some settings in the system, you can define preset values. You only need to set these values one time, then reuse the values in other screens such as the scheduling screen. If you later want to change the value, you only have to do it in one place.

Possible preset values

You can set the following user-defined preset values:

Preset value		Where used
Tank target temperature, Operation mode, Quick mode timer	[5.2] Comfort setpoint	You can use these preset values in [5.5] Schedule (weekly schedule screen for the DHW tank) if the DHW tank mode is one of the following: ▪ Schedule only ▪ Schedule + reheat
	[5.3] Eco setpoint	
	[5.4] Reheat setpoint	The software uses this preset value if the DHW tank mode is Schedule + reheat
	[5.G] Operation mode	You can select two type of DHW operation which concerns allowance of booster heater: ▪ Efficient ▪ Quick
	[5.H] Quick mode timer	This timer is only applicable if " Quick " is chosen as the Operation mode . Three preset timer can be selected: ▪ Turbo (10 minutes) ▪ Normal (20 minutes) ▪ Economic (30 minutes)

Additional to the user-defined preset values, the system also contains some system-defined preset values that you can use when programming schedules.

Example: In [7.4.2] **User settings > Quiet > Schedule** (weekly schedule for when the unit has to use which quiet mode level), you can use the following system-defined preset values: **Quiet/More quiet/Most quiet**.

10.4.2 Using and programming schedules

About schedules

Depending on your system layout and installer configuration, schedules for multiple controls may be available.

You can...	See...
Set if a specific control needs to act according to a schedule.	" Activation screen " in " Possible schedules " [▶ 61]
Select which schedule you currently want to use for a specific control. The system contains some predefined schedules. You can:	
Consult which schedule is currently selected.	" Schedule/Control " in " Possible schedules " [▶ 61]
Program your own schedules if the predefined schedules are not satisfactory. The actions you can program are control specific.	▪ "Possible actions" in "Possible schedules" [▶ 61] ▪ "10.4.3 Schedule screen: Example" [▶ 62]

Possible schedules

The table contains the following information:

- **Schedule/Control:** This column shows you where you can consult the currently selected schedule for the specific control. If needed, you can:
 - Program your own schedule. See "**10.4.3 Schedule screen: Example**" [▶ 62].
- **Predefined schedules:** (if applicable) The predefined schedule in the system for the specific control. If needed, you can program your own schedule.
- **Activation screen:** For most controls, a schedule is only effective if it activated in its corresponding activation screen. This entry shows you where to activate it.
- **Possible actions:** Actions you can use when programming a schedule.

Schedule/Control	Description
[5.5] Tank > Schedule Schedule for the domestic hot water tank temperature for your normal domestic hot water needs.	Predefined schedules: Not applicable Activation screen: Not applicable. This schedule is automatically activated if the DHW mode is one of the following: ▪ Schedule only ▪ Schedule + reheat Possible actions: ▪ Comfort: When to start heating the tank to the user-defined preset value [5.2] Comfort setpoint. ▪ Eco: When to start heating the tank to the user-defined preset value [5.3] Eco setpoint. ▪ Stop: When to stop heating the tank, even if the desired tank temperature is not reached yet. Note: In Schedule + reheat mode, the system also takes the user-defined preset value [5.4] Reheat setpoint into account.


Schedule/Control	Description
[5.F] Tank > Priority schedule Schedule for the outdoor unit to determine priority between domestic hot water tank operation and air conditioning	Predefined schedules: Domestic hot water as priority for each month Activation screen: Not applicable. This schedule is only used when more than one indoor unit (e.g. 1 tank + 1 A/C unit) connected to outdoor unit. Possible actions: ▪ DHW : If there are requests from multiple indoor units at the same time, the outdoor unit will prioritize domestic hot water production. ▪ A/C : If there are request from multiple indoor units at the same time, outdoor unit will prioritize Air Conditioning (heating/cooling) operation.
[7.4.2] User settings > Quiet > Schedule Schedule for when the unit has to use which quiet mode level.	Predefined schedule: Not applicable Activation screen: [7.4.1] Mode (only available to installers). Possible actions: You can use the following system-defined preset values: ▪ Off ▪ Quiet ▪ More quiet ▪ Most quiet See "About quiet mode" [▶ 79].

10.4.3 Schedule screen: Example

This example shows how to set a tank heat up schedule.

To program the schedule: overview

Example: You want to program the following schedule:



- 1 Go to the schedule.
- 2 (optional) Clear the content of the whole week schedule or the content of a selected day schedule.
- 3 Program the schedule for **Monday**.
- 4 Copy the schedule to the other weekdays.
- 5 Program the schedule for **Saturday** and copy it to **Sunday**.

To go to the schedule

1	Go to [5.5]: Tank > Schedule.	
---	-------------------------------	--

To clear the content of the week schedule


1	Select the name of the current schedule.	
2	Select Delete .	
3	Select OK to confirm.	

To clear the content of a day schedule





1	Select the day of which you want to clear the content. For example Friday	
2	Select Delete .	
3	Select OK to confirm.	

To program the schedule for Monday


1	Select Monday .	
2	Select Edit .	

3	Use the left dial to select an entry and edit the entry with the right dial. You can program up to 4 actions each day.  Note: To clear an action, set its time as the time of the previous action.	
4	Confirm the changes. Result: The schedule for Monday is defined. The value of the last action is valid until the next programmed action. In this example, Monday is the first day you programmed. Thus, the last programmed action is valid up to the first action of next Monday.	

To copy the schedule to the other weekdays

1	Select Monday. 	
2	Select Copy.  Result: Next to the copied day, "C" is displayed.	
3	Select Tuesday. 	
4	Select Paste.  Result: 	

5	Repeat this action for all other weekdays.	—
---	--	---



To program the schedule for Saturday and copy it to Sunday

1	Select Saturday .	
2	Select Edit .	
3	Use the left dial to select an entry and edit the entry with the right dial.	
4	Confirm the changes.	
5	Select Saturday .	
6	Select Copy .	
7	Select Sunday .	
8	Select Paste .	
	Result: 	

10.5 Weather-dependent curve

10.5.1 What is a weather-dependent curve?

Weather-dependent operation

The unit operates 'weather-dependent' if the desired tank temperature is determined automatically by the outdoor temperature. If the outdoor temperature drops or rises, the unit compensates instantly. Thus, the unit does not have to wait for feedback by the user to increase or decrease the target temperature of the tank. Because it reacts more quickly, it prevents high rises and drops of the water temperature at tap points.

Advantage

Weather-dependent operation reduces energy consumption.

Weather-dependent curve

To be able to compensate for differences in temperature, the unit relies on its weather-dependent curve. This curve defines how much the target temperature of the tank must be at different outdoor temperatures. Because the slope of the curve depends on local circumstances such as climate and the insulation of the house, the curve can be adjusted by an installer.

Types of weather-dependent curve

There are 2 types of weather-dependent curves:

- 2-points curve
- Slope-offset curve

Which type of curve you use to make adjustments, depends on your personal preference. See "10.5.4 Using weather-dependent curves" [▶ 68].

Availability

The weather-dependent curve is available for:

- Tank (only available to installers)

**INFORMATION**


To operate weather-dependent, correctly configure the setpoint of the tank. See "10.5.4 Using weather-dependent curves" [▶ 68].

10.5.2 2-points curve

Define the weather-dependent curve with these two setpoints:

- Setpoint (X1, Y2)
- Setpoint (X2, Y1)

Example



Item	Description
X1, X2	Examples of outdoor ambient temperature
Y1, Y2	Examples of desired tank temperature. The icon corresponds to the heat emitter for that zone: ▪ : Domestic hot water tank

Possible actions on this screen	
	Go through the temperatures.
	Change the temperature.
	Go to the next temperature.
	Confirm changes and proceed.

10.5.3 Slope-offset curve


Slope and offset

Define the weather-dependent curve by its slope and offset:


- Change the **slope** to differently increase or decrease the target temperature of the tank for different ambient temperatures. For example, if tank water temperature is in general fine but at low ambient temperatures too cold, raise the slope so that the tank temperature is heated increasingly more at decreasingly lower ambient temperatures.
- Change the **offset** to equally increase or decrease the target temperature of the tank for different ambient temperatures. For example, if the tank temperature is always a bit too cold at different ambient temperatures, shift the offset up to equally increase the tank target temperature for all ambient temperatures.

Examples

Weather-dependent curve when slope is selected:



Weather-dependent curve when offset is selected:



Item	Description
a	WD curve before changes.
b	WD curve after changes (as example): ▪ When slope is changed, the new preferred temperature at X1 is unequally higher than the preferred temperature at X2. ▪ When offset is changed, the new preferred temperature at X1 is equally higher as the preferred temperature at X2.
c	Slope
d	Offset
X1, X2	Examples of outdoor ambient temperature
Y1, Y2, Y3, Y4	Examples of desired tank temperature. The icon corresponds to the heat emitter for that zone: ▪ : Domestic hot water tank

Possible actions on this screen	
	Select slope or offset.
	Increase or decrease the slope/offset.
	When slope is selected: set slope and go to offset. When offset is selected: set offset.
	Confirm changes and return to the submenu.

10.5.4 Using weather-dependent curves

Configure weather-dependent curves as following:

To define the setpoint mode

To use the weather-dependent curve, you need to define the correct setpoint mode:

Go to setpoint mode ...	Set the setpoint mode to ...
Tank	
[5.B] Tank > Setpoint mode	Restriction: Only available to installers. Weather dependent

To change the type of weather-dependent curve

To change the type for the tank, go to [5.E] Tank.

- [5.E] Tank > WD curve type

Restriction: Only available to installers.

To change the weather-dependent curve

Zone	Go to ...
Tank	Restriction: Only available to installers. [5.C] Tank > WD curve



INFORMATION

Maximum and minimum setpoints

You cannot configure the curve with temperatures that are higher or lower than the set maximum and minimum setpoints for the tank. When the maximum or minimum setpoint is reached, the curve flattens out.

To fine-tune the weather-dependent curve: slope-offset curve

The following table describes how to fine-tune the weather-dependent curve of the tank:

The domestic hot water temperature is ...		Fine-tune with slope and offset:	
At regular outdoor temperatures ...	At cold outdoor temperatures ...	Slope	Offset
OK	Cold	↑	—
OK	Hot	↓	—
Cold	OK	↓	↑
Cold	Cold	—	↑

The domestic hot water temperature is ...		Fine-tune with slope and offset:	
At regular outdoor temperatures ...	At cold outdoor temperatures ...	Slope	Offset
Cold	Hot	↓	↑
Hot	OK	↑	↓
Hot	Cold	↑	↓
Hot	Hot	—	↓

See "10.5.3 Slope-offset curve" [▶ 67].

To fine-tune the weather-dependent curve: 2-points curve

The following table describes how to fine-tune the weather-dependent curve of the tank:

The domestic hot water temperature is ...		Fine-tune with setpoints:			
At regular outdoor temperatures ...	At cold outdoor temperatures ...	Y2 ^(a)	Y1 ^(a)	X1 ^(a)	X2 ^(a)
OK	Cold	↑	—	↑	—
OK	Hot	↓	—	↓	—
Cold	OK	—	↑	—	↑
Cold	Cold	↑	↑	↑	↑
Cold	Hot	↓	↑	↓	↑
Hot	OK	—	↓	—	↓
Hot	Cold	↑	↓	↑	↓
Hot	Hot	↓	↓	↓	↓


^(a) See "10.5.2 2-points curve" [▶ 66].

10.6 Settings menu

You can set additional settings using the main menu screen and its submenus. The most important settings are presented here.

10.6.1 Malfunctioning

In case of a malfunction,  or  will appear on the home screen. To display the error code, open the menu screen and go to [0] **Malfunctioning**. Press **?** for more information about the error.




[0] **Malfunctioning**

10.6.2 Tank

Overview

The following items are listed in the submenu:



[5] Tank

 Setpoint screen

[5.1] Powerful operation

[5.2] Comfort setpoint

[5.3] Eco setpoint

[5.4] Reheat setpoint

[5.5] Schedule

[5.6] Heat up mode

[5.7] Disinfection

[5.8] Maximum

[5.9] Hysteresis

[5.A] Hysteresis

[5.B] Setpoint mode

[5.C] WD curve

[5.D] Margin

[5.E] WD curve type

[5.F] Priority schedule

[5.G] Operation mode

[5.H] Quick mode timer

Tank setpoint screen

You can set the domestic hot water temperature using the setpoint screen. For more information about how to do this, see "10.3.5 Setpoint screen" [▶ 58].

Powerful operation

You can use powerful operation to immediately start heating up the water to the preset value (**Comfort setpoint**). This activates both heat pump and electrical booster heater, which results in extra energy consumption. If powerful operation is active,  will be shown on the home screen.

To activate powerful operation

Activate or deactivate **Powerful operation** as follows:

1	Go to [5.1]: Tank > Powerful operation	
2	Turn powerful operation Off or On .	

Usage example: You immediately need more hot water

If you are in the following situation:

- You already consumed most of your hot water.
- You cannot wait for the next scheduled action to heat up the storage tank.

Then you can activate DHW powerful operation.

Advantage: The storage tank is immediately heated up to the **Comfort setpoint**.

**INFORMATION**

When the Priority Schedule is set to DHW (refer to Priority schedule) and powerful operation is active, the risk of Air Conditioning (cooling /heating) and capacity shortage comfort problems is significant. In case of frequent domestic hot water operation, frequent and long Air Conditioning (cooling /heating) interruptions will happen.

Comfort setpoint

Only applicable when domestic hot water preparation is **Schedule only** or **Schedule + reheat**. When programming the schedule, you can make use of the comfort setpoint as a preset value. When you later want to change the storage setpoint, you only have to do it in one place.

The tank will heat up until the **storage comfort temperature** has been reached. It is the higher desired temperature when a storage comfort action is scheduled.

Additionally, a storage stop can be programmed. This feature puts a stop to tank heating even if the setpoint has NOT been reached. Only program a storage stop when tank heating is absolutely undesirable.

#	Code	Description
[5.2]	[6-0A]	Comfort setpoint: ▪ 30°C~[6-0E]°C

Eco setpoint

The **storage economic temperature** denotes the lower desired tank temperature. It is the desired temperature when a storage economic action is scheduled (preferably during day).

#	Code	Description
[5.3]	[6-0B]	Eco setpoint: ▪ 30°C~min(50,[6-0E])°C

Reheat setpoint

Desired reheat tank temperature, used in **Schedule + reheat** mode, during reheat mode: the guaranteed minimum tank temperature is set by the **Reheat setpoint** minus the reheat hysteresis. If the tank temperature drops below this value, the tank is heated up.

#	Code	Description
[5.4]	[6-0C]	Reheat setpoint: ▪ 30°C~min(50,[6-0E])°C

Schedule

You can set the tank temperature schedule using the schedule screen. For more information about this screen, see "10.4.3 Schedule screen: Example" [▶ 62].

Heat up mode

The domestic hot water can be prepared in 3 different ways. They differ from each other by the way the desired tank temperature is set and how the unit acts upon it.

#	Code	Description
[5.6]	[6-0D]	Heat up mode: 0: Reheat only: Only reheat operation is allowed. 1: Schedule + reheat: The domestic hot water tank is heated according to a schedule and between the scheduled heat up cycles, reheat operation is allowed. 2: Schedule only: The domestic hot water tank can ONLY be heated according to a schedule.

See the operation manual for more details.



INFORMATION

When the Priority Schedule is set to DHW (refer to Priority schedule) and the DHW tank mode is reheat only at same time, the risk for capacity shortage and comfort problem is significant. In case of frequent reheat operation, space heating/cooling function is regularly interrupted.



INFORMATION

The application of hysteresis (the amount of the temperature drop that will trigger the heat up) might vary depending on whether the target temperature is within operation range of the outdoor unit.

Disinfection

Applies only to installations with a domestic hot water tank.

The disinfection function disinfects the domestic hot water tank by periodically heating the domestic hot water to a specific temperature.




CAUTION

The disinfection function settings MUST be configured by the installer according to the applicable legislation.

#	Code	Description
[5.7.1]	[2-01]	Activation: 0: No 1: Yes
[5.7.2]	[2-00]	Operation day: 0: Every day 1: Monday 2: Tuesday 3: Wednesday 4: Thursday 5: Friday 6: Saturday 7: Sunday
[5.7.3]	[2-02]	Start time

#	Code	Description
[5.7.4]	[2-03]	Tank setpoint: 55°C~max(55, [6-0E])°C
[5.7.5]	[2-04]	Duration: 5~60 minutes



T_{DHW} Domestic hot water temperature
 T_U User setpoint temperature
 T_H High setpoint temperature [2-03]
 t Time



WARNING

Be aware that the domestic hot water temperature at the hot water tap will be equal to the value selected in field setting [2-03] after a disinfection operation.

When the high domestic hot water temperature can be a potential risk for human injuries, a mixing valve (field supply) shall be installed at the hot water outlet connection of the domestic hot water tank. This mixing valve shall secure that the hot water temperature at the hot water tap never rise above a set maximum value. This maximum allowable hot water temperature shall be selected according to the applicable legislation.



CAUTION

Make sure that the disinfection function start time [5.7.3] with defined duration [5.7.5] is NOT interrupted by possible domestic hot water demand.



NOTICE

Disinfection mode. Even if you turn OFF tank heating operation ([C.3]: **Operation** > **Tank**), disinfection mode will remain active. However, if you turn it OFF while disinfection is running, an AH error occurs.



INFORMATION

In case of error code AH and no interruption of the disinfection function occurred due to domestic hot water tapping, following actions are recommended:

- When the **Reheat only** or **Schedule + reheat** mode is selected, it is recommended to program the start-up of the disinfection function at least 4 hours later than the last expected large hot water tapping. This start-up can be set by installer settings (disinfection function).
- When the **Schedule only** mode is selected, it is recommended to program an **Eco** action 3 hours before the scheduled start-up of the disinfection function to preheat the tank.

**INFORMATION**

Disinfection function is restarted in case the domestic hot water temperature drops 5°C below the disinfection target temperature within the duration time.

Maximum DHW temperature setpoint

The maximum temperature that users can select for the domestic hot water. You can use this setting to limit the temperatures at the hot water taps.

**INFORMATION**

During disinfection of the domestic hot water tank, the DHW temperature can exceed this maximum temperature.

**INFORMATION**

Limit the maximum hot water temperature according to the applicable legislation.

Hysteresis (heat pump ON hysteresis)

Applicable when domestic hot water preparation is reheat only. When the tank temperature drops below the reheat temperature minus the heat pump ON hysteresis temperature, the tank heats up to the reheat temperature.

#	Code	Description
[5.9]	[6-00]	Heat pump ON hysteresis ▪ 2°C~20°C

Hysteresis (reheat hysteresis)

Applicable when domestic hot water preparation is scheduled+reheat. When the tank temperature drops below the reheat temperature minus the reheat hysteresis temperature, the tank heats up to the reheat temperature.

#	Code	Description
[5.A]	[6-08]	Reheat hysteresis ▪ 2°C~20°C

**INFORMATION**

To ensure most optimum operation of the outdoor unit, we recommend to set the hysteresis to 6°C or higher.

**INFORMATION**

If Reheat setpoint is outside operation range of the outdoor unit, then the hysteresis will refer to the the highest temperature achievable by heat pump operation.

Setpoint mode


#	Code	Description
[5.B]	N/A	Setpoint mode: ▪ Fixed ▪ Weather dependent

WD curve

When weather-dependent operation is active the desired tank temperature is determined automatically depending on the averaged outdoor temperature: low outdoor temperatures will result in higher desired tank temperatures as the cold water tap is colder and vice versa.

In case of **Schedule only** or **Schedule + reheat** domestic hot water preparation, the storage comfort temperature is weather-dependent (according to the weather-dependent curve), the storage economic and reheat temperature are NOT weather-dependent.

In case of **Reheat only** domestic hot water preparation, the desired tank temperature is weather-dependent (according to the weather-dependent curve). During weather-dependent operation, the end-user cannot adjust the desired tank temperature on the user interface. Also see "10.5 Weather-dependent curve" [▶ 65].


#	Code	Description
[5.C]	[0-0E] [0-0D] [0-0C] [0-0B]	WD curve: Note: There are 2 methods to set the weather dependent curve. See "10.5.2 2-points curve" [▶ 66] and "10.5.3 Slope-offset curve" [▶ 67] for more information about the different curve types. Both curve types require 4 field settings to be configured according to the figure below.  ▪ T_{DHW}: The desired tank temperature. ▪ T_a: The (averaged) outdoor ambient temperature ▪ [0-0E]: low outdoor ambient temperature: $-40^{\circ}\text{C} \sim 5^{\circ}\text{C}$ ▪ [0-0D]: high outdoor ambient temperature: $10^{\circ}\text{C} \sim 25^{\circ}\text{C}$ ▪ [0-0C]: desired tank temperature when the outdoor temperature equals or drops below the low ambient temperature: $\text{Min}(45, [6-0E])^{\circ}\text{C} \sim [6-0E]^{\circ}\text{C}$ ▪ [0-0B]: desired tank temperature when the outdoor temperature equals or rises above the high ambient temperature: $35^{\circ}\text{C} \sim [6-0E]^{\circ}\text{C}$

Margin

In domestic hot water operation, the following hysteresis value can be set for the heat pump operation:

#	Code	Description
[5.D]	[6-01]	The temperature difference determining the heat pump OFF temperature. Range: 0°C~10°C

Example: setpoint (T_U) > maximum heat pump temperature – [6-01] ($T_{HP\ MAX} - [6-01]$)



BSH Booster heater

HP Heat pump. If heating up time by the heat pump takes too long, auxiliary heating by the booster heater can take place if Quick mode is selected.

$T_{BSH\ OFF}$ Booster heater OFF temperature (T_U)

$T_{HP\ MAX}$ Maximum heat pump temperature at sensor in domestic hot water tank

$T_{HP\ OFF}$ Heat pump OFF temperature ($T_{HP\ MAX} - [6-01]$)


$T_{HP\ ON}$ Heat pump ON temperature ($T_{HP\ OFF} - [6-00]$) or ($T_{HP\ OFF} - [6-08]$)

T_{DHW} Domestic hot water temperature

T_U User setpoint temperature (as set on the user interface)

t Time

Example: setpoint (T_U) ≤ maximum heat pump temperature – [6-01] ($T_{HP\ MAX} - [6-01]$)



HP Heat pump. If heating up time by the heat pump takes too long, auxiliary heating by the booster heater can take place if Quick mode is selected.

$T_{HP\ MAX}$ Maximum heat pump temperature at sensor in domestic hot water tank

$T_{HP\ OFF}$ Heat pump OFF temperature ($T_{HP\ MAX} - [6-01]$)

$T_{HP\ ON}$ Heat pump ON temperature ($T_{HP\ OFF} - [6-00]$) or ($T_{HP\ OFF} - [6-08]$)

T_{DHW} Domestic hot water temperature

T_U User setpoint temperature (as set on the user interface)

t Time



INFORMATION

The maximum heat pump temperature depends on the ambient temperature. For more information, see the operation range.

WD curve type

There are 2 methods to define the weather-dependent curves:

- 2-points (see "10.5.2 2-points curve" ▶ 66)

- **Slope-Offset** (see "10.5.3 Slope-offset curve" [▶ 67])

In [2.E] **WD curve type**, you can choose which method you want to use.

In [5.E] **WD curve type**, the chosen method is shown read-only (same value as in [2.E]).

#	Code	Description
[2.E] / [5.E]	N/A	▪ 0: 2-points ▪ 1: Slope-Offset

Priority Schedule

In case multiple indoor units (e.g. 1 Tank, 1 Air conditioning) This setting selects the operation that should be prioritized (can be set for each month) by the outdoor unit: Domestic hot water (DHW) or Air conditioning (A/C). Depending on the selected priority, the outdoor unit can either decide to handle both operation together (not possible if A/C is requesting cooling operation) or performing only one of the requested operation.

#	Code	Description
[5.F]	[A-00]	Priority schedule: ▪ 0: DHW ▪ 1: A/C

If DHW and A/C requests happen at the same time, the possible outcomes based on scheduled Priority settings are as follow⁽¹⁾:

If ...			The heat pump operation = ...
Which is priority?	A/C request is ...	Can outdoor unit do both? ^(a)	
DHW	Cooling	-	DHW, while A/C is put on hold
	Heating	Yes	DHW and A/C together
		No	DHW, while A/C is put on hold
A/C	Cooling	-	A/C, while DHW is by booster heater
	Heating	Yes	DHW and A/C together
		No	A/C, while DHW is by booster heater

^(a) Decided by outdoor unit.

Operation mode and Quick mode timer

During Domestic hot water (DHW) production, the booster heater allowance⁽²⁾ can be selected/limited as follows:

⁽¹⁾ *applicable when outdoor ambient temperature and tank target temperature are within operation range of outdoor unit

⁽²⁾ When ambient temperature and/or target temperature is outside the operation range of outdoor unit, booster heater is also allowed to operate, refer to "Operation" [▶ 84].


#	Code	Description
[5.G]	[A-01]	Priority schedule: 0: Efficient: Booster heater is prohibited^(a), except when outdoor unit is unable to do DHW (see Priority schedule) 1: Quick: Booster heater is allowed to assist heat pump during DHW production
[5.H]	[8-03]	When Quick is selected, the booster heater can start after a delay timer to assist the heat pump operation. The delay time is depending on the selected Quick mode timer : Turbo (10 minutes) Normal (20 minutes) Economic (30 minutes)

^(a) When tank disinfection is performed with **Efficient** mode, the booster heater can still start after 20 minutes to assist the heat pump.

10.6.3 User settings

Overview

The following items are listed in the submenu:



[7] User settings

[7.1] Language

[7.2] Time/date

[7.3] Holiday

[7.4] Quiet

Language

#	Code	Description
[7.1]	N/A	Language

Time/date

#	Code	Description
[7.2]	N/A	Set the local time and date



INFORMATION

By default, daylight savings time is enabled and clock format is set to 24 hours. These settings can be changed during initial configuration or via the menu structure [7.2]: **User settings > Time/date**.

Holiday

About holiday mode

During your holiday, you can use the holiday mode to deviate from your normal schedules without having to change them. While holiday mode is active, domestic hot water operation will be turned off. Disinfection operation will remain active.

Typical workflow


Using holiday mode typically consists of the following stages:

- 1 Activating the holiday mode.
- 2 Setting the starting date and ending date of your holiday.

To check if holiday mode is activated and/or running

If  is displayed on the home screen, holiday mode is active.

To configure the holiday

1	Activate the holiday mode.	—
	Go to [7.3.1]: User settings > Holiday > Activation. 	
	Select On.	
2	Set the first day of your holiday.	—
	Go to [7.3.2]: From.	
	Select a date.	 
	Confirm the changes.	
3	Set the last day of your holiday.	—
	Go to [7.3.3]: Till.	
	Select a date.	 
	Confirm the changes.	

Quiet

About quiet mode

You can use quiet mode to decrease the sound of the outdoor unit. However, this also decreases the heating/cooling capacity of the system. There are multiple quiet mode levels.

The installer can:

- Completely deactivate quiet mode
- Manually activate a quiet mode level
- Enable the user to program a quiet mode schedule
- Configure restrictions based on local regulations

If enabled by the installer, the user can program a quiet mode schedule.



INFORMATION

If the outdoor temperature is below zero, we recommend to NOT use the most quiet level.

To check if quiet mode is active

If  is displayed on the home screen, quiet mode is active.

To use quiet mode

1	Go to [7.4.1]: User settings > Quiet > Mode.	
2	Do one of the following:	—

If you want to...	Then...	
Completely deactivate quiet mode	Select Off . Result: The unit never runs in quiet mode. The user cannot change this.	
Manually activate a quiet mode level	Select Manual .	
	Go to [7.4.3] Level and select the applicable quiet mode level. Example: Most quiet. Result: The unit always runs in the selected quiet mode level. The user cannot change this.	
▪ Enable the user to program a quiet mode schedule, AND/OR ▪ Configure restrictions based on local regulations	Select Automatic . Result: ▪ The user (or you) can program the schedule in [7.4.2] Schedule. For more information about scheduling, see "10.4.3 Schedule screen: Example" [▶ 62]. ▪ You can configure restrictions in [7.4.4] Restrictions. See below. ▪ The possible outcomes for the quiet mode differ depending on the schedule (if programmed) and the restrictions (if enabled/defined). See below.	

To configure restrictions

1	Enable the restrictions. Go to [7.4.4.1]: User settings > Quiet > Restrictions > Enable and select Yes .	
2	Define the restrictions (time + level) to be used before midday (AM): ▪ [7.4.4.2] AM Restricted time Example: From 9 a.m. to 11 a.m. ▪ [7.4.4.3] AM Restricted level Example: More quiet	

3	Define the restrictions (time + level) to be used after midday (PM): [7.4.4.4] PM Restricted time Example: From 3 p.m. to 7 p.m. [7.4.4.5] PM Restricted level Example: Most quiet	
----------	---	--


Possible outcomes when quiet mode is set to Automatic

If...			Then quiet mode =...
Restrictions enabled?	Restrictions (time + level) defined?	Schedule programmed?	
No	N/A	No	OFF
		Yes	Follows schedule
Yes	No	No	OFF
		Yes	Follows schedule
	Yes	No	Follows restriction
		Yes	During restricted time: If restricted level is stricter than scheduled level, then follows restriction. Else, follows schedule. Outside restricted time: Follows schedule.

10.6.4 Information

Overview

The following items are listed in the submenu:



[8] Information

- [8.2] Malfunction history
- [8.3] Dealer information
- [8.4] Sensors
- [8.5] Actuators
- [8.6] Operation modes
- [8.7] About
- [8.8] Connection status
- [8.9] Running hours
- [8.A] Reset

Dealer information

The installer can fill in his contact number here.

#	Code	Description
[8.3]	N/A	Number that users can call in case of problems.

Reset

Reset the configuration settings stored in the MMI (user interface of the indoor unit).

Example: Holiday settings.

**INFORMATION**

This does not reset the configuration settings and field settings of the indoor unit.

#	Code	Description
[8.A]	N/A	Reset the MMI EEPROM to factory default


Possible read-out information

In menu...	You can read out...
[8.2] Malfunction history	Malfunction history
[8.3] Dealer information	Contact/helpdesk number
[8.4] Sensors	Outdoor temperature, Tank temperature.
[8.5] Actuators	Status/mode of each actuator Booster heater
[8.6] Operation modes	Current operation mode Example: Defrost/oil return mode
[8.7] About	Version information about the system
[8.8] Connection status	Information about the connection status of the unit, the room thermostat and WLAN.
[8.9] Running hours	Running hours of specific system components

10.6.5 Installer settings

Overview

The following items are listed in the submenu:

**[9] Installer settings**

- [9.1] Configuration wizard
- [9.4] Booster heater
- [9.5] Emergency
- [9.9] Power consumption control
- [9.E] Auto restart
- [9.F] Power saving function
- [9.G] Disable protections
- [9.I] Overview field settings
- [9.N] Export MMI settings

Configuration wizard

After first power ON of the system, the user interface will guide you using the configuration wizard. This way you can set the most important initial settings. This way the unit will be able to run properly. Afterwards, more detailed settings can be done via the menu structure if required.

To restart the configuration wizard, go to **Installer settings > Configuration wizard** [9.1].

Booster heater

Booster heater capacity

The capacity of the booster heater must be set for the power consumption control feature to work properly. When measuring the resistance value of the booster heater, you can set the exact heater capacity and this will lead to more accurate energy data (e.g. for Power consumption control). The capacity of the booster heater installed in the domestic hot water tank is 1,2 kW.

#	Code	Description
[9.4.1]	[6-02]	Booster heater capacity [kW]. The capacity of the booster heater at nominal voltage. Range: 0~10 kW

Quick mode timer

#	Code	Description
[9.4.3]	[8-03]	Booster heater delay timer. Start-up delay time for the booster heater when heat pump domestic hot water mode is active and tank operation mode is Quick, refer to "10.6.2 Tank" [▶ 70]. - When heat pump domestic hot water mode is active and tank operation mode is Quick, the delay time is 20 minutes by default. End user can select 3 predefined values: 10, 20, or 30 minutes, see Operation mode, refer to "Operation mode and Quick mode timer" [▶ 77]. - The delay time starts from the moment the heat pump begins domestic hot water production. - By adapting the booster heater delay time versus the maximum running time, you can find an optimal balance between the energy efficiency and the heat up time. - If the booster heater delay time is set too high, it might take a long time before the domestic hot water reaches its set temperature. Range: 5~95 minutes. If Installer set values of [8-03] other than the 3 preset values for end user, it will be displayed in Tank > Quick mode timer as "set by installer". We recommend to select one of the preset values for end user.

Operation

#	Code	Description
[9.4.4]	[4-03]	Defines the operation permission of the booster heater depending on ambient, domestic hot water temperature or operation mode of heat pump.
[9.4.4]	[4-03]	▪ 0 Restricted: Booster heater operation is NOT allowed except for "Disinfection function" and "Powerful domestic water heating". Only use this in case the heat pump capacity can cover the heating requirements of the house and domestic hot water during the complete heating season.
[9.4.4]	[4-03]	▪ 1 Allowed: Booster heater operation is allowed when required.
[9.4.4]	[4-03]	▪ 2 Overlap: The booster heater is allowed outside the operation range of the heat pump for domestic hot water operation. Booster heater operation is only allowed if: - Ambient temperature is out of the operating range: $T_a < -15\text{ }^{\circ}\text{C}$ or $T_a > 42\text{ }^{\circ}\text{C}$ - Domestic hot water temperature is $2\text{ }^{\circ}\text{C}$ lower than the heat pump OFF temperature.
9.4.4	[4-03]	▪ 3 Compressor off: The booster heater is allowed when the heat pump is NOT active in domestic hot water operation. Same as setting 1, but simultaneous heat pump domestic hot water operation and booster heater operation is not allowed.



INFORMATION

If the selected value of [4-03] is other than 1, the Quick mode will not work, see Operation mode, refer to "[Quick mode timer](#)" [▶ 83].

Emergency

Emergency

When the heat pump fails to operate, the booster heater can serve as an emergency heater. It then takes over the heat load either automatically or by manual interaction.

- When **Emergency** is set to **Automatic** and a heat pump failure occurs, the booster heater in the tank automatically takes over the domestic hot water production.
- When **Emergency** is set to **Manual** and a heat pump failure occurs, the domestic hot water heating stops.

To manually recover it via the user interface, go to the **Malfunctioning** main menu screen and confirm whether the booster heater can take over the heat load or not.

To keep energy consumption low, we recommend to set **Emergency** to **Manual** if the house is unattended for longer periods.

#	Code	Description
[9.5.1]	[4-06]	0: Manual 1: Automatic



INFORMATION

The auto emergency setting can be set in the menu structure of the user interface only.

Power consumption control

Power consumption control

See "[6 Application guidelines](#)" [▶ 23] for detailed information about this functionality.

#	Code	Description
[9.9.1]	[4-08]	Power consumption control: 0 No: Disabled. 1 Continuous: Enabled: You can set one power limitation value (in A or kW) to which the system power consumption will be limited for all the time.
[9.9.2]	[4-09]	Type: 0 Amp: The limitation values are set in A. 1 kW: The limitation values are set in kW.

Limit when [9.9.1]=**Continuous** and [9.9.2]=**Amp**:

#	Code	Description
[9.9.3]	[5-05]	Limit : Only applicable in case of full time current limitation mode. 12 A~50 A

Limit when [9.9.1]=**Continuous** and [9.9.2]=**kW**:

#	Code	Description
[9.9.8]	[5-09]	Limit : Only applicable in case of full time power limitation mode. 3 kW~20 kW

Sensors

Averaging time

The average timer corrects the influence of ambient temperature variations. The weather-dependent setpoint calculation is done on the average outdoor temperature.

The outdoor temperature is averaged over the selected time period.

#	Code	Description
[9.B.3]	[1-0A]	Averaging time: 0: No averaging 1: 12 hours 2: 24 hours 3: 48 hours 4: 72 hours

Auto restart

Auto restart

When power returns after a power supply failure, the auto restart function reapplies the user interface settings at the time of the power failure. Therefore, it is recommended to always enable the function.

#	Code	Description
[9.E]	[3-00]	Auto restart: 0: Manual 1: Automatic

Power saving function

Defines whether the outdoor unit power supply can be interrupted (internally by indoor unit control) during stand-still conditions (no air conditioning nor domestic hot water demand). The final decision to allow power interruption of the outdoor unit during standstill depends on the ambient temperature, compressor conditions and minimum internal timers.

To enable the power saving function setting, [E-08] needs to be enabled on the user interface.

#	Code	Description
[9.F]	[E-08]	Power saving function for outdoor unit: 0: No 1: Yes

Disable protections

Protective functions

The unit is equipped with the following protective function:

- Tank disinfection [2-01]

#	Code	Description
[9.G]	N/A	Disable protections: 0: No 1: Yes



INFORMATION

Protective functions – "Installer-on-site mode". The software is equipped with protective functions, such as tank disinfection. The unit automatically runs these functions when necessary.

During installation or service this behaviour is undesired. Therefore, the protective functions can be disabled:

- **At first power-on:** The protective functions are disabled by default. After 36 hours they will be automatically enabled.
- **Afterwards:** An installer can manually disable the protective functions by setting [9.G]: **Disable protections**=Yes. After his work is done, he can enable the protective functions by setting [9.G]: **Disable protections**=No.

Overview field settings

Almost all settings can be done using the menu structure. If for any reason it is required to change a setting using the overview settings, then the overview settings can be accessed in the field settings overview [9.I]. See ["To modify an overview setting"](#) [► 53].


Export MMI settings

About exporting the configuration settings

Export the configuration settings of the unit to a USB memory stick, via the MMI (the user interface of the indoor unit). When troubleshooting, these settings can be provided to our Service department.

#	Code	Description
[9.N]	N/A	Your MMI settings will be exported to the connected storage device: ▪ Back ▪ OK


To export MMI settings

1	Insert a USB memory stick in the user interface.	—
		
2	On the user interface, go to [9.N] Export MMI settings .	
3	Select OK .	
4	Remove the USB memory stick.	—

10.6.6 Commissioning

Overview

The following items are listed in the submenu:



[A] Commissioning


- [A.1] Operation test run
- [A.2] Actuator test run

About commissioning

See: "11 Commissioning" [▶ 93]

10.6.7 User profile

[B] User profile: See "To change the user permission level" [▶ 52].




[B] User profile

10.6.8 Operation

Overview

The following items are listed in the submenu:



[C] Operation

- [C.3] Tank

To enable or disable functionalities

In the operation menu, you can separately enable or disable functionalities of the unit.

#	Code	Description
[C.3]	N/A	Tank: 0: Off 1: On


10.6.9 WLAN

**INFORMATION**

Restriction: WLAN settings are only visible when a WLAN cartridge is inserted in the user interface.

Overview

The following items are listed in the submenu:




[D] Wireless gateway

- [D.1] Mode
- [D.2] Reboot
- [D.3] WPS
- [D.4] Remove from cloud
- [D.5] Home network connection
- [D.6] Cloud connection

About the WLAN cartridge

The WLAN cartridge connects the system to the internet. The user can then control the system via the ONECTA app.

This needs the following components:



a	WLAN cartridge	The WLAN cartridge needs to be inserted in the user interface. See the installation manual of the WLAN cartridge.
b	Router	Field supply.
c	Smartphone + app	The ONECTA app needs to be installed on the user's smartphone. See: http://www.onlinecontroller.daikineurope.com/



Configuration

To configure the ONECTA app, follow the in-app instructions. While doing this, the following actions and information are needed on the user interface:

Mode: Turn AP mode ON (= WLAN adapter active as access point) or OFF.

#	Code	Description
[D.1]	N/A	Enable AP mode: ▪ No ▪ Yes

Reboot: Reboot the WLAN cartridge.

#	Code	Description
[D.2]	N/A	Reboot the gateway: ▪ Back ▪ OK

WPS: Connect the WLAN cartridge to the router.

#	Code	Description
[D.3]	N/A	WPS: ▪ No ▪ Yes



INFORMATION

You can only use this function if it is supported by the software version of the WLAN, and the software version of the ONECTA app.

Remove from cloud: Remove the WLAN cartridge from the cloud.

#	Code	Description
[D.4]	N/A	Remove from cloud: ▪ No ▪ Yes


Home network connection: Read out the status of the connection to the home network.

#	Code	Description
[D.5]	N/A	Home network connection: ▪ Disconnected from [WLAN_SSID] ▪ Connected to [WLAN_SSID]

Cloud connection: Read out the status of the connection to the cloud.

#	Code	Description
[D.6]	N/A	Cloud connection: ▪ Not connected ▪ Connected

10.7 Menu structure: Overview user settings



Setpoint screen

(*) Only applicable when the tank Operation Mode is Quick

(**) Only accessible by installer


(***) Only applicable when WLAN is installed



INFORMATION

Depending on the selected installer settings and unit type, settings will be visible/invisible.

10.8 Menu structure: Overview installer settings



(*) Can NOT be adjusted



INFORMATION

Depending on the selected installer settings and unit type, settings will be visible/invisible.

11 Commissioning



NOTICE

General commissioning checklist. Next to the commissioning instructions in this chapter, a general commissioning checklist is also available on the Daikin Business Portal (authentication required).

The general commissioning checklist is complementary to the instructions in this chapter and can be used as a guideline and reporting template during commissioning and hand-over to the user.



INFORMATION

Protective functions – "Installer-on-site mode". The software is equipped with protective functions, such as tank disinfection. The unit automatically runs these functions when necessary.

During installation or service this behaviour is undesired. Therefore, the protective functions can be disabled:

- **At first power-on:** The protective functions are disabled by default. After 36 hours they will be automatically enabled.
- **Afterwards:** An installer can manually disable the protective functions by setting [9.G]: **Disable protections=Yes**. After his work is done, he can enable the protective functions by setting [9.G]: **Disable protections=No**.

Also see "[Protective functions](#)" [▶ 86].

In this chapter

11.1	Overview: Commissioning	93
11.2	Precautions when commissioning	93
11.3	Checklist before commissioning	94
11.4	Checklist during commissioning	94
11.4.1	Operation test run	95
11.4.2	Actuator test run	95

11.1 Overview: Commissioning

This chapter describes what you have to do and know to commission the system after it is installed and configured.

Typical workflow

Commissioning typically consists of the following stages:

- 1 Checking the "Checklist before commissioning".
- 2 Performing a test run for the system.
- 3 If necessary, performing a test run for one or more actuators.

11.2 Precautions when commissioning



INFORMATION

During the first running period of the unit, the required power may be higher than stated on the nameplate of the unit. This phenomenon is caused by the compressor, that needs a continuous run time of 50 hours before reaching smooth operation and stable power consumption.

**NOTICE**

ALWAYS operate the unit with thermistors and/or pressure sensors/switches. If NOT, burning of the compressor might be the result.

**NOTICE**

ALWAYS complete the refrigerant piping of the unit before operating. If NOT, the compressor will break.

11.3 Checklist before commissioning

- 1 After the installation of the unit, check the items listed below.
- 2 Close the unit.
- 3 Power up the unit.

☐	You read the complete installation instructions, as described in the installer reference guide .
☐	The indoor unit is properly mounted.
☐	The outdoor unit is properly mounted.
☐	The following field wiring has been carried out according to this document and the applicable legislation: ▪ Between the local supply panel and the outdoor unit ▪ Between indoor unit and outdoor unit ▪ Between the local supply panel and the indoor unit
☐	The system is properly earthed and the earth terminals are tightened.
☐	The fuses or locally installed protection devices are installed according to this document, and have NOT been bypassed.
☐	The power supply voltage matches the voltage on the identification label of the unit.
☐	There are NO loose connections or damaged electrical components in the switch box.
☐	There are NO damaged components or squeezed pipes on the inside of the indoor and outdoor units.
☐	Booster heater circuit breaker F2B (field supply) is turned ON.
☐	There are NO refrigerant leaks .
☐	The refrigerant pipes (gas and liquid) are thermally insulated.
☐	The correct pipe size is installed and the pipes are properly insulated.
☐	There is NO water leak inside the indoor unit.
☐	The stop valves (gas and liquid) on the outdoor and indoor units are fully open.
☐	The domestic hot water tank is filled completely.

11.4 Checklist during commissioning

☐	To perform a test run .
--------------------------	--------------------------------

To perform an **actuator test run**.

11.4.1 Operation test run

Purpose

Perform test runs on the unit and monitor the tank temperature to check if the unit is working correctly. The following test run should be made:

- Tank

To perform an operation test run

Conditions: Make sure all operation is disabled. Go to [C]: **Operation** and turn off Tank operation.

To monitor tank temperatures

During test run, the correct operation of the unit can be checked by monitoring its tank temperature (domestic hot water mode).

To monitor the temperatures:

1	In the menu, go to Sensors .	
2	Select the temperature information.	
1	Set the user permission level to Installer . See "To change the user permission level" [▶ 52].	—
2	Go to [A.1]: Commissioning > Operation test run .	
3	Select the Tank ..	
4	Select OK to confirm. Result: The test run starts. It stops automatically when ready (±30 min).	
	To stop the test run manually:	—
1	In the menu, go to Stop test run .	
2	Select OK to confirm.	



INFORMATION

If the outdoor temperature is outside the range of operation, the unit may NOT operate or may NOT deliver the required capacity.

11.4.2 Actuator test run

Purpose

Perform an actuator test run to confirm the operation of the different actuators. For example, when you select **Booster heater**, a test run of the booster heater will start.

To perform an actuator test run

Conditions: Make sure all operation is disabled. Go to [C]: **Operation** and turn off Tank operation.

1	Set the user permission level to Installer . See "To change the user permission level" [▶ 52].	—
---	---	---

2	Go to [A.2]: Commissioning > Actuator test run.	
3	Select Booster heater.	
4	Select OK to confirm. Result: The actuator test run starts. It stops automatically when ready (± 30 min).	
	To stop the test run manually:	—
1	In the menu, go to Stop test run.	
2	Select OK to confirm.	

Possible actuator test runs

- Booster heater test

12 Hand-over to the user

Once the test run is finished and the unit operates properly, make sure the following is clear for the user:

- Fill in the installer setting table (in the operation manual) with the actual settings.
- Make sure that the user has the printed documentation and ask him/her to keep it for future reference. Inform the user that he can find the complete documentation at the URL mentioned earlier in this manual.
- Explain the user how to properly operate the system and what to do in case of problems.
- Show the user what to do for the maintenance of the unit.
- Explain the user about energy saving tips as described in the operation manual.

13 Maintenance and service



NOTICE

General maintenance/inspection checklist. Next to the maintenance instructions in this chapter, a general maintenance/inspection checklist is also available on the Daikin Business Portal (authentication required).

The general maintenance/inspection checklist is complementary to the instructions in this chapter and can be used as a guideline and reporting template during maintenance.



NOTICE

Maintenance **MUST** be done by an authorised installer or service agent.

We recommend performing maintenance at least once a year. However, applicable legislation might require shorter maintenance intervals.



NOTICE

Applicable legislation on **fluorinated greenhouse gases** requires that the refrigerant charge of the unit is indicated both in weight and CO₂ equivalent.

Formula to calculate the quantity in CO₂ equivalent tonnes: GWP value of the refrigerant × total refrigerant charge [in kg] / 1000

In this chapter

13.1	Maintenance safety precautions.....	98
13.2	Yearly maintenance	98
13.2.1	Yearly maintenance indoor unit: overview.....	98
13.2.2	Yearly maintenance indoor unit: instructions	99
13.3	To drain the domestic hot water tank	100

13.1 Maintenance safety precautions



DANGER: RISK OF ELECTROCUTION



DANGER: RISK OF BURNING/SCALDING



NOTICE: Risk of electrostatic discharge

Before performing any maintenance or service work, touch a metal part of the unit in order to eliminate static electricity and to protect the PCB.

13.2 Yearly maintenance

13.2.1 Yearly maintenance indoor unit: overview

- Pressure relief valve of the domestic hot water tank
- Switch box
- Booster heater of the domestic hot water tank

- Anode

13.2.2 Yearly maintenance indoor unit: instructions

Pressure relief valve of the domestic hot water tank (field supply)

Open the valve.



CAUTION

Water coming out of the valve may be very hot.

- Check if nothing blocks the water in the valve or in between piping. The water flow coming from the relief valve must be high enough.
- Check if the water coming out of the relief valve is clean. If it contains debris or dirt:
 - Open the valve until the discharged water does not contain debris or dirt anymore.
 - Flush and clean the complete tank, including the piping between the relief valve and cold water inlet.

To make sure this water originates from the tank, check after a tank heat up cycle.



INFORMATION

It is recommended to perform this maintenance more than once a year.

Switch box

- Carry out a thorough visual inspection of the switch box and look for obvious defects such as loose connections or defective wiring.
- Using an ohmmeter, check if contactor K3M operates correctly. All contacts of this contactor must be in open position when the power is turned OFF.



WARNING

If the internal wiring is damaged, it has to be replaced by the manufacturer, its service agent or similarly qualified persons.

Booster heater of the domestic hot water tank

It is recommended to remove lime buildup on the booster heater to extend its life span, especially in regions with hard water. To do so, drain the domestic hot water tank, remove the booster heater from the domestic hot water tank and immerse in a bucket (or similar) with lime-removing product for 24 hours.



NOTICE

The booster heater sealing must be replaced after every check. Tighten the booster heater screws to 10 N•m of torque.

Anode

To check the integrity of the magnesium anode drain the domestic hot water tank, remove the booster heater from the domestic hot water tank and check the anode. If corrosion affects more than 2/3 of the anode surface, please replace it.

**NOTICE**

The booster heater sealing must be replaced after every check. Tighten the booster heater screws to 10 N•m of torque.

13.3 To drain the domestic hot water tank

**DANGER: RISK OF BURNING/SCALDING**

The water in the tank can be very hot.


Prerequisite: Stop the unit operation via the user interface.

Prerequisite: Turn OFF the respective circuit breaker.

Prerequisite: Close the cold water supply.

Prerequisite: Open all the hot water tapping points to allow air to enter the system.

- 1** Remove the water inlet connection, the water will flow out of the tank.



- a** DHW – hot water OUT (screw connection, ½")
b DHW – cold water IN (screw connection, ½")

14 Troubleshooting

In this chapter

14.1	Overview: Troubleshooting	101
14.2	Precautions when troubleshooting.....	101
14.3	Solving problems based on symptoms.....	102
14.3.1	Symptom: Hot water does NOT reach the desired temperature	102
14.3.2	Symptom: The pressure at the tapping point is temporarily unusually high	102
14.3.3	Symptom: Tank disinfection function is NOT completed correctly (AH-error)	102
14.4	Solving problems based on error codes.....	102
14.4.1	To display the help text in case of a malfunction.....	103
14.4.2	Error codes: Overview.....	103

14.1 Overview: Troubleshooting

This chapter describes what you have to do in case of problems.

It contains information about:

- Solving problems based on symptoms
- Solving problems based on error codes

Before troubleshooting

Carry out a thorough visual inspection of the unit and look for obvious defects such as loose connections or defective wiring.

14.2 Precautions when troubleshooting



DANGER: RISK OF ELECTROCUTION



DANGER: RISK OF BURNING/SCALDING



WARNING

- When carrying out an inspection on the switch box of the unit, ALWAYS make sure that the unit is disconnected from the mains. Turn off the respective circuit breaker.
- When a safety device was activated, stop the unit and find out why the safety device was activated before resetting it. NEVER shunt safety devices or change their values to a value other than the factory default setting. If you are unable to find the cause of the problem, call your dealer.



WARNING

Prevent hazards due to inadvertent resetting of the thermal cut-out: power to this appliance MUST NOT be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly turned ON and OFF by the utility.

14.3 Solving problems based on symptoms

14.3.1 Symptom: Hot water does NOT reach the desired temperature

Possible causes	Corrective action
One of the tank temperature sensors is broken.	See the service manual of the unit for the corresponding corrective action.

14.3.2 Symptom: The pressure at the tapping point is temporarily unusually high

Possible causes	Corrective action
Failing or blocked pressure relief valve.	- Flush and clean the complete tank including the piping between pressure relief valve and the cold water inlet. - Replace the pressure relief valve.

14.3.3 Symptom: Tank disinfection function is NOT completed correctly (AH-error)

Possible causes	Corrective action
The disinfection function was interrupted by domestic hot water tapping	Program the start-up of the disinfection function when the coming 4 hours NO domestic hot water tapping is expected.
Large domestic hot water tapping happened recently before the programmed start-up of the disinfection function	If in [5.6] Tank > Heat up mode the mode Reheat only or Schedule + reheat is selected, it is recommended to program the start-up of the disinfection function at least 4 hours later than the last expected large hot water tapping. This start-up can be set by installer settings (disinfection function). If in [5.6] Tank > Heat up mode the mode Schedule only is selected, it is recommended to program a Eco action 3 hours before the scheduled start-up of the disinfection function to preheat the tank.
The disinfection operation was stopped manually: [C.3] Operation > Tank was turned off during disinfection.	Do NOT stop tank operation during disinfection.

14.4 Solving problems based on error codes

If the unit runs into a problem, the user interface displays an error code. It is important to understand the problem and to take measures before resetting an error code. This should be done by a licensed installer or by your local dealer.

This chapter gives you an overview of most possible error codes and their descriptions as they appear on the user interface.

**INFORMATION**

See the service manual for:

- The complete list of error codes
- A more detailed troubleshooting guideline for each error

14.4.1 To display the help text in case of a malfunction

In case of a malfunction, the following will appear on the home screen depending on the severity:

- : Error
- : Malfunction

You can get a short and a long description of the malfunction as follows:

1	Press the left dial to open the main menu and go to Malfunctioning . Result: A short description of the error and the error code is displayed on the screen.	
2	Press ? in the error screen. Result: A long description of the error is displayed on the screen.	?

**WARNING**

In case F3-00, there is possible risk of refrigerant leak. Contact your installer.

14.4.2 Error codes: Overview

Error codes of the unit

Error code	Description	
89-01		Heat exchanger freeze-up protection activated during defrost (error)
89-02		Heat exchanger freeze-up protection activated during heating / DHW operation. (warning)
89-03		Heat exchanger freeze-up protection activated during defrost (warning)
A1-00		Zero cross detection problem
A5-00		OU: High pressure peak cut / freeze protection problem
AH-00		Tank disinfection function not completed correctly
AJ-03		Too long DHW heat-up time required
C4-00		Heat exchanger temperature sensor problem
C5-00		Heat exchanger thermistor abnormality
E1-00		OU: PCB defect
E3-00		OU: Actuation of high pressure switch (HPS)

Error code		Description
E3-24		High pressure sensor abnormality
E5-00		OU: Overheat of inverter compressor motor
E6-00		OU: Compressor startup defect
E7-00		OU: Malfunction of outdoor unit fan motor
E8-00		OU: Power input overvoltage
EA-00		OU: Cool/heat switchover problem
EC-00		Abnormal increase tank temperature
F3-00		OU: Malfunction of discharge pipe temperature
F6-00		OU: Abnormal high pressure in cooling
F8-00		Compressor internal error
H0-00		OU: Voltage/current sensor problem
H3-00		OU: Malfunction of high pressure switch (HPS)
H6-00		OU: Malfunction of position detection sensor
H8-00		OU: Malfunction of compressor input (CT) system
H9-00		OU: Malfunction of outdoor air thermistor
HC-00		Tank temperature sensor problem
J3-00		OU: Malfunction of discharge pipe thermistor
J3-10		Compressor port thermistor abnormality
J6-00		OU: Malfunction of heat exchanger thermistor
J6-07		OU: Malfunction of heat exchanger thermistor
J6-32		Leaving water temperature thermistor Abnormality (outdoor unit)
J8-00		Malfunction of refrigerant liquid thermistor
J9-00		Malfunction of refrigerant gas thermistor
JA-00		OU: Malfunction of high pressure sensor
L1-00		Malfunction of INV PCB
L3-00		OU: Electrical box temperature rise problem
L4-00		OU: Malfunction of inverter radiating fin temperature rise
L5-00		OU: Inverter instantaneous overcurrent (DC)
L8-00		Malfunction triggered by a thermal protection in the inverter PCB
P1-00		Open-phase power supply imbalance

Error code	Description	
P4-00		OU: Malfunction of radiating fin temperature sensor
PJ-00		Capacity setting mismatch
U0-00		OU: Shortage of refrigerant
U2-00		OU: Defect of power supply voltage
U4-00		Indoor/outdoor unit communication problem
U5-00		User interface communication problem
U6-38		Extension/hydro communication problem
U7-00		OU: Transmission malfunction between main CPU-INV CPU
U8-04		Unknown USB device
U8-05		File malfunction
U8-07		P1P2 communication error
U8-09		MMI software version {version_MMI_software} / Indoor unit [version_IU_modelname] compatibility error
U8-11		Connection with the Wireless gateway lost
UA-00		Indoor unit, outdoor unit matching problem
UA-17		Tank type problem
UF-00		Reversed piping or bad communication wiring detection.
UH-00		Indoor unit malfunction or frost in other indoor units



INFORMATION

In case of error code F3-00, there is a possible risk of refrigerant leak.



INFORMATION

In case of error code AH and no interruption of the disinfection function occurred due to domestic hot water tapping, following actions are recommended:

- When the **Reheat only** or **Schedule + reheat** mode is selected, it is recommended to program the start-up of the disinfection function at least 4 hours later than the last expected large hot water tapping. This start-up can be set by installer settings (disinfection function).
- When the **Schedule only** mode is selected, it is recommended to program an **Eco** action 3 hours before the scheduled start-up of the disinfection function to preheat the tank.



INFORMATION

Error AJ-03 is reset automatically from the moment there is a normal tank heat-up.

**INFORMATION**

If an U8-04 error occurs, the error can be reset after a successful update of the software. If the software is not successfully updated then you must make sure that your USB device has the FAT32 format.

**INFORMATION**

If the booster heater overheats and is disabled by the thermostatic safety, the unit will not give an error directly. Check if the booster heater is still in operation if you experience one or more of the following errors:

- Powerful operation takes a very long time to heat up and the error code AJ-03 is displayed.
- During anti-legionella operation (weekly), the error code AH-00 is displayed because the unit cannot reach the requested temperature required for tank disinfection.

**INFORMATION**

A malfunctioning booster heater will have an impact on energy metering and power consumption control.

**INFORMATION**

The user interface will display how to reset an error code.


15 Technical data

A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible). The **full set** of latest technical data is available on the Daikin Business Portal (authentication required).

In this chapter

15.1	Piping diagram: Indoor unit.....	108
15.2	Wiring diagram: Indoor unit.....	109

15.1 Piping diagram: Indoor unit



- a1** Domestic hot water – hot water out
- a2** Domestic hot water – cold water in
- b1** Liquid stop valve
- b2** Gas stop valve
- c** Booster heater

- Thermistors:**
- R3T** Thermistor heat exchanger – Liquid pipe
 - R5T** Tank thermistor

15.2 Wiring diagram: Indoor unit

See the internal wiring diagram supplied with the unit (on the inside of the indoor unit switch box cover). The abbreviations used are listed below.






Legend

A1P		Main PCB
F2B	#	Overcurrent fuse booster heater
FU1 (A1P)		Fuse (5 A 250 V for PCB)
K3M		Contactor booster heater
Q1DI	#	Earth leakage circuit breaker
TR1		Power supply transformer
X4M	#	Booster heater power supply terminal strip client
X8M		Booster heater power supply terminal strip
X*, X*A, X*B		Connector
X*M		Terminal strip

* Optional
Field supply


Translation of text on wiring diagram

English	Translation
(1) Connection diagram	(1) Connection diagram
Compressor switch box	Compressor switch box
Multi+DHW Tank switch box	Multi domestic hot water tank switch box
Indoor	Indoor
Outdoor	Outdoor
SWB	Switch box
(2) Legend	(2) Legend
A1P	Main PCB
F2B	Overcurrent fuse booster heater
FU1 (A1P)	fuse (5 A 250 V for PCB)
K3M	Contactor booster heater
Q1DI	Earth leakage circuit breaker
TR1	Power supply transformer
X4M	Booster heater power supply terminal strip client
X8M	Booster heater power supply terminal strip
X*, X*A, X*B	Connector

X*M	Terminal strip
(3) Notes	(3) Notes
X2M	Field wiring terminal for AC
X4M	Booster heater power supply terminal strip client
X5M	Wiring terminal for DC (Indoor)
X5M	Field wiring terminal for AC (Outdoor)
X8M	Booster heater power supply terminal strip
	Earth wiring
	Field supply
	Option
	Not mounted in switch box
	Wiring depending on model
	PCB
Note 1: Connection point of the power supply for the BSH should be foreseen outside the unit	Note 1: Connection point of the power supply for the booster heater should be foreseen outside the unit.
(4) Switch box layout	(4) Switch box layout
SWB	Switch box

Electrical connection diagram

For more details, please check the unit wiring.



16 Glossary

Dealer

Sales distributor for the product.

Authorised installer

Technical skilled person who is qualified to install the product.

User

Person who is owner of the product and/or operates the product.

Applicable legislation

All international, European, national and local directives, laws, regulations and/or codes that are relevant and applicable for a certain product or domain.

Service company

Qualified company which can perform or coordinate the required service to the product.

Installation manual

Instruction manual specified for a certain product or application, explaining how to install, configure and maintain it.

Operation manual

Instruction manual specified for a certain product or application, explaining how to operate it.

Maintenance instructions

Instruction manual specified for a certain product or application, which explains (if relevant) how to install, configure, operate and/or maintain the product or application.

Accessories

Labels, manuals, information sheets and equipment that are delivered with the product and that need to be installed according to the instructions in the accompanying documentation.

Optional equipment

Equipment made or approved by Daikin that can be combined with the product according to the instructions in the accompanying documentation.

Field supply

Equipment NOT made by Daikin that can be combined with the product according to the instructions in the accompanying documentation.

Field settings table



Applicable indoor units



EKHWET90BAV3
EKHWET120BAV3



Field settings table					Installer setting at variance with default value	
Breadcrumb	Field code	Setting name		Range, step Default value	Date	Value
Tank						
5.2	[6-0A]	Comfort setpoint	R/W	30~[6-0E]°C, step: 1°C 50°C		
5.3	[6-0B]	Eco setpoint	R/W	30~min(50, [6-0E])°C, step: 1°C 45°C		
5.4	[6-0C]	Reheat setpoint	R/W	30~min(50, [6-0E])°C, step: 1°C 45°C		
5.6	[6-0D]	Heat up mode	R/W	0: Reheat only 1: Reheat + sched. 2: Scheduled only		
└ Disinfection						
5.7.1	[2-01]	Activation	R/W	0: No 1: Yes		
5.7.2	[2-00]	Operation day	R/W	0: Each day 1: Monday 2: Tuesday 3: Wednesday 4: Thursday 5: Friday 6: Saturday 7: Sunday		
5.7.3	[2-02]	Start time	R/W	0~23 hour, step: 1 hour 1		
5.7.4	[2-03]	Tank setpoint	R/W	55~max(55, 6-0E)~75°C, step: 1°C 70°C		
5.7.5	[2-04]	Duration	R/W	5~60 min, step: 5 min 10 min		
Tank						
5.8	[6-0E]	Maximum	R/W	40~75°C, step: 1°C 75°C		
5.9	[6-00]	Hysteresis	R/W	2~20°C, step: 1°C 6°C		
5.A	[6-08]	Hysteresis	R/W	2~20°C, step: 1°C 10°C		
5.B		Setpoint mode	R/W	0: Fixed 1: Weather dependent		
└ WD curve						
5.C	[0-0B]	Setting temperature water value for high ambient temp. for DHW WD curve.	R/W	35~[6-0E]°C, step: 1°C 43°C		
5.C	[0-0C]	Setting temperature water value for low ambient temp. for DHW WD curve.	R/W	45~[6-0E]°C, step: 1°C 50°C		
5.C	[0-0D]	High ambient temp. for DHW WD curve.	R/W	10~25°C, step: 1°C 25°C		
5.C	[0-0E]	Low ambient temp. for DHW WD curve.	R/W	-40~5°C, step: 1°C -15°C		
Tank						
5.D	[6-01]	Margin	R/W	0~10°C, step: 1°C 2°C		
5.F	[A-00]	Priority schedule	R/W	0: DHW 1: Air Conditioning		
5.G	[A-01]	Operation mode	R/W	0: Efficient 1: Quick		
5.H	[8-03]	Quick mode timer	R/W	Turbo: 10 min Normal: 20 min Economic: 30 min		
User settings						
└ Quiet						
7.4.1		Mode	R/W	0: OFF 1: Manual 2: Automatic		
7.4.3		Level	R/W	0: Quiet 1: More Quiet 2: Most Quiet		
Installer settings						
└ Configuration wizard						
└ System						
9.1.3.3	[E-05] [E-06] [E-07]	Domestic hot water	R/O	Integrated		
9.1.3.4	[4-06]	Emergency	R/W	0: Manual 1: Automatic		
9.1.3.7	[6-02]	BSH capacity	R/W	0~10kW, step: 0,2kW 1.2kW		
└ Tank						
9.1.B.1	[6-0D]	Heat up mode	R/W	0: Reheat only 1: Reheat + sched. 2: Scheduled only		
9.1.B.2	[6-0A]	Comfort setpoint	R/W	30~[6-0E]°C, step: 1°C 50°C		
9.1.B.3	[6-0B]	Eco setpoint	R/W	30~min(50, [6-0E])°C, step: 1°C 45°C		
9.1.B.4	[6-0C]	Reheat setpoint	R/W	30~min(50, [6-0E])°C, step: 1°C 45°C		
9.1.B.6	[6-08]	Reheat hysteresis	R/W	2~20°C, step: 1°C 10°C		
└ Booster heater						
9.4.1	[6-02]	Capacity	R/W	0~10kW, step: 0,2kW 1.2kW		
9.4.3	[8-03]	Quick mode timer	R/W	5~95 min, step: 5 min 20 min		
9.4.4	[4-03]	Operation	R/W	0: Restricted 1: Allowed 2: Overlap 3: Compressor off		
└ Emergency						

Field settings table						Installer setting at variance with default value	
Breadcrumb	Field code	Setting name		Range, step Default value		Date	Value
9.5.1	[4-06]	Emergency	R/W	0: Manual 1: Automatic			
└─ Power consumption control							
9.9.1	[4-08]	Power consumption control	R/W	0: No limitation 1: Continuous			
9.9.2	[4-09]	Type	R/W	0: Current 1: Power			
9.9.3	[5-05]	Limit	R/W	12~50 A, step: 1 A 12 A			
9.9.8	[5-09]	Limit	R/W	3~20 kW, step: 0,5 kW 3 kW			
9.9.D	[4-01]	Priority heater	R/O	0: None 1: BSH 2: BUH			
└─ Sensors							
9.B.3	[1-0A]	Averaging time	R/W	0: No averaging 1: 12 hours 2: 24 hours 3: 48 hours 4: 72 hours			
Installer settings							
9.E	[3-00]	Auto restart	R/W	0: No 1: Yes			
9.F	[E-08]	Power saving function	R/W	0: Disabled 1: Enabled			
9.G		Disable protections	R/W	0: No 1: Yes			
└─ Overview field settings							
9.I	[0-0B]	Setting temperature water value for high ambient temp. for DHW WD curve.	R/W	35~[6-0E]°C, step: 1°C 43°C			
9.I	[0-0C]	Setting temperature water value for low ambient temp. for DHW WD curve.	R/W	45~[6-0E]°C, step: 1°C 50°C			
9.I	[0-0D]	High ambient temp. for DHW WD curve.	R/W	10~25°C, step: 1°C 25°C			
9.I	[0-0E]	Low ambient temp. for DHW WD curve.	R/W	-40~5°C, step: 1°C -15°C			
9.I	[1-0A]	What is the averaging time for the outdoor temp?	R/W	0: No averaging 1: 12 hours 2: 24 hours 3: 48 hours 4: 72 hours			
9.I	[2-00]	When should the disinfection function be executed?	R/W	0: Each day 1: Monday 2: Tuesday 3: Wednesday 4: Thursday 5: Friday 6: Saturday 7: Sunday			
9.I	[2-01]	Should the disinfection function be executed?	R/W	0: No 1: Yes			
9.I	[2-02]	When should the disinfection function start?	R/W	0~23 hour, step: 1 hour 1			
9.I	[2-03]	What is the disinfection target temperature?	R/W	55~max(55, 6-0E), step: 1°C 70°C			
9.I	[2-04]	How long must the tank temperature be maintained?	R/W	5~60 min, step: 5 min 10 min			
9.I	[3-00]	Is auto restart of the unit allowed?	R/W	0: No 1: Yes			
9.I	[4-01]	Which electric heater has priority?	R/O	0: None 1: BSH 2: BUH			
9.I	[4-03]	Operation permission of the booster heater.	R/W	0: Restricted 1: Allowed 2: Overlap 3: Compressor off			
9.I	[4-06]	Emergency	R/W	0: Manual 1: Automatic			
9.I	[4-08]	Which power limitation mode is required on the system?	R/W	0: No limitation 1: Continuous			
9.I	[4-09]	Which power limitation type is required?	R/W	0: Current 1: Power			
9.I	[5-05]	What is the requested limit for DI1?	R/W	12~50 A, step: 1 A 12 A			
9.I	[5-09]	What is the requested limit for DI1?	R/W	3~20 kW, step: 0,5 kW 3 kW			
9.I	[6-00]	The temperature difference determining the heat pump ON temperature.	R/W	2~20°C, step: 1°C 6°C			
9.I	[6-01]	The temperature difference determining the heat pump OFF temperature.	R/W	0~10°C, step: 1°C 2°C			
9.I	[6-02]	What is the capacity of the booster heater?	R/W	0~10kW, step: 0,2kW 1.2kW			
9.I	[6-08]	What is the hysteresis to be used in reheat mode?	R/W	2~20°C, step: 1°C 10°C			
9.I	[6-0A]	What is the desired comfort storage temperature?	R/W	30~[6-0E]°C, step: 1°C 50°C			
9.I	[6-0B]	What is the desired eco storage temperature?	R/W	30~min(50, [6-0E])°C, step: 1°C 45°C			
9.I	[6-0C]	What is the desired reheat temperature?	R/W	30~min(50, [6-0E])°C, step: 1°C 45°C			
9.I	[6-0D]	What is the desired DHW production type?	R/W	0: Reheat only 1: Reheat + sched. 2: Scheduled only			
9.I	[6-0E]	What is the maximum DHW temperature setpoint?	R/W	40~75°C, step: 1°C 75°C			

Field settings table				Installer setting at variance with default value	
Breadcrumb	Field code	Setting name	Range, step Default value	Date	Value
9.I	[7-00]	Domestic hot water booster heater overshoot temperature.	R/W 0~4°C, step: 1°C 0°C		
9.I	[7-01]	Domestic hot water booster heater hysteresis.	R/W 2~40°C, step: 1°C 2°C		
9.I	[8-03]	Booster heater delay timer (or Quick mode timer).	R/W 5~95 min, step: 5 min 20 min		
9.I	[A-00]	Which indoor unit operation is prioritized by outdoor unit?	R/W 0: DHW 1: Air Conditioning		
9.I	[A-01]	Which operation mode is used for domestic hot water production?	R/W 0: Efficient 1: Quick		
9.I	[A-02]	--	1		
9.I	[A-03]	--	0		
9.I	[A-04]	--	0		
9.I	[B-00]	--	0		
9.I	[B-01]	--	0		
9.I	[B-02]	--	0		
9.I	[B-03]	--	0		
9.I	[B-04]	--	0		
9.I	[E-00]	Which type of unit is installed?	R/O 0~5 4: DHWHP		
9.I	[E-01]	Which type of compressor is installed?	R/O 0		
9.I	[E-02]	What is the indoor unit software type?	R/O 1: Heating only		
9.I	[E-04]	Is the power saving function available on the outdoor unit?	R/O 0: No 1: Yes		
9.I	[E-05]	Can the system prepare domestic hot water?	R/W 0: No 1: Yes		
9.I	[E-06]	Is a DHW tank installed in the system?	R/O 0: No 1: Yes		
9.I	[E-07]	What kind of DHW tank is installed?	R/O 0~8 0: EKHW, small volume 1: Integrated 2: Tank with BSH 3: EKHW, large volume 5: EKHWP 7: Third party tank, small coil 8: Third party tank, large coil		
9.I	[E-08]	Power saving function for outdoor unit.	R/W 0: Disabled 1: Enabled		
9.I	[F-0A]	--	0		







DAIKIN EUROPE N.V.

Zandvoordestraat 300, B-8400 Oostende, Belgium

4P680077-1A 2022.11